

Limited Warranty Information

Thank you for choosing our product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, and Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion within the warranty period. A valid proof of purchase with the purchase date clearly indicated must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**

The products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage, is considered negligence and will not be covered under this warranty. The use of "hard water" and/or caustic cleaners can affect the painted or other finishes. Failure to keep the unit clean and use of such additives/cleaners will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading within the first year from date of purchase with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. You must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. Item is covered under one year limited warranty from the date of purchase. When requesting replacement parts due to a warranty claim after 30 days of purchase, credit card information will be requested for shipping charges.

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to

1. Damages caused in Transit
2. Inadequate care and/or neglect
3. Environmental and/or natural elements
4. Immersion in water, unless specified
5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.








Red Butterfly Metal Bench



Assembling & Using Your Product


Unpack all components carefully. Please check to ensure all parts have been removed from the packaging. There some splashing may occur.

Components:


PART A 1 PC	PART C 2 PCS	PART E 2PCS	
			
PART B 1PC	PART D 1 PC	LG:12PCS	SM:2PCS
			

Assembling:


Step 1: Attach both backrest (Part C) pieces together using the round butterfly head (Part A) by inserting the screw coming from the butterfly head to the hole found on each upper part of the backrest pieces. Use the two (2) SM nuts and secure a nut on each screw by turning clockwise tightly. **(See diagrams below)**




Step 2: Place the assembled backrest (Part A + C) on a leveled surface and attach the seat (Part B) by inserting the screws coming from the seat into the holes found on the assembled backrest, then secure by using four (4) LG nuts and screw clockwise tightly. **(See diagrams below)**



Step 3: Attach the two (2) legs (Part E) by inserting the screws coming from the seat (Part B) into the holes found at the top of the legs, secure it by using two (2) LG nuts PER leg and screw clockwise tightly. Before securing with the nuts, make sure the legs are placed in the correct direction with the curve facing outward. **(See diagram below)**



Step 4: Attach the bottom support (Part D) by inserting the screws coming from the bottom support into the holes found on the legs (Part E) and bottom backrest (Part C). Secure it together by using four (4) LG nuts and screwing the nuts in clockwise tightly. **(See diagram below)**



Your garden furniture is now completely assembled.