














Parker Living®
HORIZON

DC#313HD



ASSEMBLY INSTRUCTION

<p>① × 1</p> 	<p>② × 1</p> 	<p>③ × 2</p> 	<p>④ × 1</p> 	<p>⑤ × 1</p> 		
<p>⑥ × 1</p> 	<p>⑦ × 5</p> 	<p>⑧ × 1</p>  <p>M5</p>	<p>⑨ × 2</p>  <p>M8×22</p>	<p>⑩ × 2</p>  <p>M8×38</p>	<p>⑪ × 8</p>  <p>M8×32</p>	<p>⑫ × 8</p> 