


ASSEMBLY INSTRUCTIONS


OUTDOOR CHAIR - CUSHION COVER

1

BACK CUSHION COVER





FLIP THE SEAT
CUSHION COVER
UPSIDE DOWN



CUSHION COVER


2

BACK CUSHION




SEAT CUSHION

3




UNZIP COVER
THEN
INSERT
CUSHIONS
INTO COVERS




4

ZIP
THE ZIPPER



FLIP THE SEAT
CUSHION COVER
UPSIDE DOWN



5



FABRICS MAINTENANCE



Direction of maintenance :

1. Machine wash in luke warm water (up to 40°C,100°F) at a gentle setting (reduced agitation).
2. A mild bleach agent can be used for cleaning, Avoid concentrated bleach application.
3. Ironing (Low 110 ° C, 230 ° F).
4. Do not dryclean.
5. Tumble dry, low permanent press.