








ASSEMBLY INSTRUCTIONS

CONSOLE TABLE

NESTING CONSOLE PARTS & HARDWARE LIST

Please assemble with the tool provided or recommended. Do not use an impact drill.

 <p>(A) TABLE TOP x 1</p>	 <p>(B) LSF SIDE FRAME x 1</p>	 <p>(C) RSF SIDE FRAME x 1</p>
 <p>(D) BACK SUPPORT x 1</p>		
 <p>(H2) ALLEN BOLT(Ø5/16" *45MM) x 12 SPRING WASHER(5/16") x 12 FLAT WASHER(5/16") x 12</p>	 <p>(H4) DOWEL x 4 (Ø8*30mm)</p>	 <p>(H5) ALLEN KEY x 1 (M4)</p>









NOTES :

1. CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
2. REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
3. UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
4. DO NOT OVER - TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
5. WITH USE, SCREW/ BOLT MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.



ROLLING CONSOLE PARTS & HARDWARE LIST

Please assemble with the tool provided or recommended. Do not use an impact drill.








 <p>Ⓔ</p> <p>TABLE TOP x 1</p>	 <p>Ⓕ</p> <p>LSF SIDE FRAME x 1</p>	 <p>Ⓖ</p> <p>RSF SIDE FRAME x 1</p>
 <p>Ⓗ</p> <p>BACK SUPPORT x 1</p>		
 <p>Ⓗ1</p> <p>ALLEN BOLT(Ø5/16" *51 MM) x 4 SPRING WASHER(5/16") x 4 FLAT WASHER(5/16") x 4</p>	 <p>Ⓗ3</p> <p>ALLEN BOLT(Ø5/16" *38 MM) x 6 SPRING WASHER(5/16") x 6 FLAT WASHER(5/16") x 6</p>	 <p>Ⓗ4</p> <p>DOWEL x 4 (Ø8*30mm)</p>
 <p>Ⓗ5</p> <p>ALLEN KEY x 1 (M4)</p>		

- CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
- REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
- UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
- DO NOT OVER - TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
- WITH USE, SCREW/ BOLT MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.



STOOL PARTS & HARDWARE LIST

Please assemble with the tool provided or recommended. Do not use an impact drill.


 <p>① SEAT BOX x 1</p>	 <p>② BACK SIDE FRAME x 1</p>	 <p>③ FRONT SIDE FRAME x 1</p>
 <p>④ SIDE STRETCHER x 2</p>		
 <p>⑤ ALLEN BOLT(Ø5/16" *45 MM) x 12 SPRING WASHER(5/16") x 12 FLAT WASHER(5/16") x 12</p>	 <p>⑥ DOWEL x 12 (Ø8*30mm)</p>	 <p>⑦ ALLEN KEY x 1 (M4)</p>

NOTES :

- CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
- REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
- UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
- DO NOT OVER - TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
- WITH USE, SCREW/ BOLT MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.




HARDWARE BLISTER PACKS ARE STORED INSIDE THE NESTING CONSOLE




STEP 1 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened




STEP 2 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened




CONSOLE TABLE



ASSEMBLY COMPLETED


STEP 3 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened




STEP 4 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened




CONSOLE TABLE



ROLLING CONSOLE ASSEMBLY COMPLETED


STEP 5 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened




STEP 6 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened



STEP 7 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened



STEP 8 (x1)

Do not over-tighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened

