


Ash & Willow

USE AND CARE GUIDE

ASHLAND 2-PERSON BROWN WICKER OUTDOOR BENCH



Customer Service : 1-855-975-2287

Our customer service staff is available to help you. For any problem with your purchase, or to receive further information about this product, please call our toll-free number.

SAVE THIS MANUAL

Keep this manual and the original sales invoice in a safe, dry place for future reference.

Table of Contents

Table of Contents	2	Hardware Included.	3
Safety Information	2	Bench Package Contents	4
Warranty	2	Assembly.	5
Pre-Assembly	3	Care and Cleaning	6
Planning Assembly.	3		

Important Safety Instructions

SAVE THESE INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



CAUTION: Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!

Warranty

Thank you for purchasing this product. These products have been made to demanding, high-quality, standards and are guaranteed for domestic use against manufacturing defects for a period of one (1) year following the date of purchase.

In case of any malfunction of your product (failure, missing part, etc.), please contact one of our service technicians at our toll-free service line at 1-855-975-2287 from 8 AM to 6 PM, Monday to Friday, Eastern time. You could also contact us at warrantycare@1800acs.com.

The product is guaranteed if used for normal residential purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair. Heavy-duty or daily professional/commercial usage is not covered by the warranty. Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.

Care and Cleaning

- ❑ Do not allow water to build up in the frames. This will cause corrosion and possible freezing damage in cold climates.
- ❑ Use a mild soap and water for normal cleaning. Do not use alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- ❑ Rinse with clean water and dry with a soft, absorbent cloth towel.
- ❑ Treat the frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.
- ❑ Over time, the color of the fabric will fade under prolonged outdoor exposure. This is considered normal wear.
- ❑ For best color preservation, keep chairs indoors when not in use.

Pre-Assembly

PLANNING ASSEMBLY


Please read this entire instruction manual prior to assembly.

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a non-abrasive surface to avoid scratching.

**NOTE:** More than one person may be required to assemble this product.

HARDWARE INCLUDED

**NOTE:** Hardware not shown to actual size.




Part	Description	Quantity
AA	M6x40 bolt	4
BB	M6x25 bolt	4
CC	Washer	8
DD	Bolt cap	8
EE	Allen driver	1

Pre-Assembly

BENCH PACKAGE CONTENTS

IMPORTANT: Do not fully tighten bolts until all pieces are loosely assembled.



Part	Description	Quantity
A	Back panel	1
B	Seat panel	1
C	Right arm panel	1
D	Left arm panel	1
E	Seat cushion	1

Assembly

- 1

Attach the back panel and seat panel to the left arm panel


□ Attach the back panel (A) and seat panel (B) to the left arm panel (D) using M6 bolts (AA and BB) and washers (CC).
- 2

Attach the right arm panel to back panel and seat panel

□ Attach the right arm panel (C) to back panel (A) and seat panel (B) using M6 bolts (AA and BB) and washers (CC).

NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (EE) to tighten. Do not fully tighten bolts until all pieces are loosely assembled. Add corresponding caps (DD) after final assembly finished.

NOTE: Please ensure all the bolts are assembled correctly and use the allen driver (EE) to tighten. Do not fully tighten bolts until all pieces are loosely assembled. Add corresponding caps (DD) after final assembly finished.



- 3

Add cushion

□ Add the seat cushion (E) on the bench.

