





Hardware installation demonstration

NOTE: Please make sure "A" hardware tightened and can't be pulled out!


I





II
























III







A	B	C	D	E	F	G	H	I	LED
									
24PCS	24PCS	24PCS	48PCS	12PCS	12PCS	4PCS	6PCS	6PCS	1PCS


1  2000*3501PCS	2  2000*3331PCS	3  500*3331PCS	4  500*3331PCS	5  500*3331PCS
6  500*3331PCS	7  501*3653PCS	8  475*3131PCS	9  978*3331PCS	10  974*3101PCS
11  482*3053PCS	12  484*5101PCS	13  493*5101PCS	14  987*1591PCS	15  987*3441PCS




Hardware installation demonstration

NOTE: Please make sure "A" hardware tightened and can't be pulled out!


I




II



III



1



A*16





C*4









E*12




I*6




2



A*8



C*16




D*12







F*12

3




B*8

4





B*8

5



B*8

6



D*36





G*4



H*6

7

The following
installation LED
lights



LED Light

If you can't let the lights work successfully, please check the following:

1. Please check the direction of the connect, try it in the opposite direction, according to the following picture.
2. Please check the remote control, it need you to tear down the plastic septum before use it.
3. Don't let the remote control too far from the receiver, make sure there is no obstruction between them.

