

正面

ANTIQUE TELEPHONE USER'S MANUAL

Function:

1. Global telephone switches supported.
2. PULSE/TONE compatible.
3. Retro classic rotary dialing keypad.
4. Digital or mechanical ringer available, varies with models.
5. Redial function

Installation:

1. Insert the modular plugs of the coiled handset cord into the jack of the telephone handset and into the jack at the bottom of the telephone base.
2. Insert the modular plug of the straight-line cord into the modular jack at the bottom of the telephone base.
3. When using, you must dial clockwise and touch the RD button to complete a number dialing. And so on, until you finish dialing.

Sketch Map:



Hands Free Function:

Hands free talk is provided. Press the "HANDS FREE" button in the round center and dial the number, then it enters into the handset-free conversation; you can transfer to a handset talk by picking up the landline handset; Similarly, in a handset mode, you can transfer to a speaker mode by pressing the "HANDS FREE" button and put the handset back to the phone. The best distance for hands-free calling is 30 centimeters (Speaker function may not be included varying with models).

Redial Function:

This function is used when the called is busy. To redial the last number, just hang up your handset and re-pick it up, then press the RD button; or press HANDS Free after hang up, and then press RD to redial the last number.

Warm Reminds:

1. Never dial counterclockwise, which would result in irreversible damage.
2. Place the phone on a flat desktop for a more convenient dialing.

背面