
INSTALLATION
Product Manual

Version: 510060 US-00-26A-HB


Installation Instructions




Tools Required for Installation



Icons and their uses you will see throughout this manual



You will need to make sure that your assembly is square before tightening your bolts.




This icon warns you to not over tighten your bolts. This is to prevent structural damage and also splintering your wood.



For proper assembly you will need to ensure that your structure is level before proceeding to the next step.



This icon will show you what dril! attachments are needed. For this example you will need a Phillips head attachment .




Some steps in the assembly process will require an extra set ofhands. Make sure you have a helper available.




This size of the open-end wrench on these icons should correspond to the size of the nut.


Wood Components (Not to Scale)




Front left pillar
Qty: 1




Front right pillar
Qty: 1




Front left beam
Qty: 1




Front right beam
Qty: 1




Left crossbeam
Qty: 1




Right crossbeam
Qty: 1




Middle crossbeam
Qty: 2




Central crossbeam
Qty: 1




Column right support bar
Qty: 2




Left pillar support
Qty: 2




Top middle cover strip
Qty: 7




Top edge cover strip
Qty: 14



Rear left bar
Qty: 1




Rear right bar
Qty: 1




support strip
Qty: 1


Hardware Components




Wooden tenons




black Screw




black Screw




black Screw




screws




screws




Screw




Flat washer




Hex key



Hex key




connect iron sheet




Earth screw

Front horizontal bar installation


Step 1



Front left beam
Qty: 1





Front right beam
Qty: 1



support strip
Qty: 1


1. Use hardware B to pass through component 16 and install it towards the lead hole






Front horizontal bar installation


Step 2




Left crossbeam
Qty: 1



Right crossbeam
Qty: 1




Middle crossbeam
Qty: 2




Central crossbeam
Qty: 1

1. Place the components according to the diagram, and insert the notches into the notches




Rear horizontal bar installation


Step 3





Rear left bar
Qty: 1




Rear right bar
Qty: 1








1. Connect with hardware A first, then install with hardware C
2. Component 7 Install hardware D according to the diagram




Top strip installation


Step 4



Top middle cover strip
Qty: 7




1. Use hardware C to pass through component 12 and install it towards the lead hole




Top strip installation


Step 5



Top edge cover strip
Qty: 14




1. One end of component 13 is pressing against one end of component 12
2. Use hardware C to pass through component 13 and install it towards the lead hole




Front pillar installation


Step 6





Front left pillar
Qty: 1




Front right pillar
Qty: 1











1. Distinguish the direction of the left and right pillars
2. Thread hardware E through hardware H, and then use tool hardware I to install component

Installation of support bars


Step 7




Column right support bar
Qty: 2




Left pillar support
Qty: 2





1. Thread hardware F through hardware H, and then use tool hardware I to install component




Installation of support bars

Step 8

M6*40	Ø21/Ø8	M6
G x 8	H x 8	J x 1


1. Thread hardware G through hardware H, and then use tool hardware J to install component




Rear horizontal bar installation

Step 9


1. Doing this requires collaboration from two or more people
2. Use hardware C to pass through component 14,15 and install it towards the lead hole







Installation of corner code


Step 10







1. Use hardware L to pass through Hardware K and Installed underground
2. Use hardware B to pass through Hardware K and install it towards the lead hole



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT



adelahu@fufugaga.com



208-820-0068
208-820-0799