


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY

DIFFICULT

Tools Required For Assembly:

- Allen Wrench

(Included)
- Wrench

(Included)
- Phillips Screwdriver

(Not Included)




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Headboard




#2 x 2pcs
Leg Headboard (L&R)




#3 x 1pc
Footboard



#4 x 2pcs
Side Rail




#5 x 1set
Slat (10pcs)




#I x 1pc
Allen Wrench M4


Hardware List




#A x 4pcs
Dowel Ø3/8" x 1-9/16"




#B x 8pcs
Threaded Pin 1/4" x 2-3/8"




#C x 8pcs
Half Moon




#D x 8pcs
Hexagon Nut 1/4" x 7/16"




#E x 20pcs
Wood Screw Ø1/6" x 1-3/16"



#F x 8pcs
Short Bolt (Ø15)1/4" x 2"




#G x 8pcs
Flat washer Ø3/4"




#H x 1pc
Wrench M11


Exploded View



Prepare 8 bolts assembly by inserting washer (#G) onto bolts (#F). Align headboard legs (#2R/L) to the holes of the headboard (#1). Secure by using bolts (#F).


#F x 8pcs
#G x 8pcs






Attach dowels (#A) and threaded pins (#B) to the holes of the headboard (#1) and footboard (#3). Align side rails (#4) to the dowels (#A) and threaded pins (#B) of the headboard (#1) and footboard (#3). Secure by using half moon washer (#C) and hex nut (#D).

#A x 4pcs
#B x 8pcs
#C x 8pcs
#D x 8pcs




Align slats (#5) to the side rails (#4), then secure by using screws (#E).

#E x 20pcs



Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT


Tools Required For Assembly:

Allen Wrench



(Included)

Wrench




(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.






FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.





Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List

	#1 x 1pc Headboard
	#2 x 2pcs Leg Headboard (L&R)
	#3 x 1pc Footboard
	#4 x 2pcs Side Rail
	#5 x 1set Slat (10pcs)
	#6 x 2pcs Support Leg 310x35x35mm
	#I x 1pc Allen Wrench M4

Hardware List



	#A x 4pcs Dowel Ø3/8" x 1-9/16"
	#B x 8pcs Threaded Pin 1/4" x 2-3/8"
	#C x 8pcs Half Moon
	#D x 8pcs Hex Nut Ø1/4" x 7/16"
	#E x 20pcs Screw Ø1/6" x 1-3/16"
	#F x 8pcs Short Bolt Ø1/4" x 2"
	#G x 8pcs Flat washer Ø3/4"
	#H x 1pc Wrench M11

Exploded View



Prepare 8 bolts assembly by inserting washer (#G) onto bolts (#F). Align headboard legs (#2R/L) to the holes of the headboard (#1). Secure by using bolts (#F).


#F x 8pcs
#G x 8pcs






#A x 4pcs
#B x 8pcs
#C x 8pcs
#D x 8pcs

Attach dowels (#A) and threaded pins (#B) to the holes of the headboard (#1) and footboard (#3). Align side rails (#4) to the dowels (#A) and threaded pins (#B) of the headboard (#1) and footboard (#3). Secure by using half moon washer (#C) and hex nut (#D).





Attach support legs (#6) to the slat kit (#5). Adjust leveler on the support legs (#6) according to ground level.






Align slats (#5) to the side rails (#4), then secure by using screws (#E).

#E x 20pcs



ASSEMBLY IS COMPLETED

Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench




(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED

ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.







FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1pc Front panel
	#2 x 1pc Back panel
	#3 x 2pcs Left & right side panel
	#4 x 3pcs Bottom panel
	#5 x 4pcs Slats

Hardware List

	#A x 8pcs Dowel Ø5/16"x1-3/16"
	#B x 8pcs Short Bolt Ø1/4"x1-3/16"
	#C x 8pcs Screw Ø1/6" x 3/4"
	#D x 4pcs Caster
	#E x 2pcs Pine Knob 3/16"*1-3/16"
	#F x 2pcs Ph Zinc (knob)
	#G x 32pcs Crew Ø1/6" x 1"
	#H x 1pc Allen Wrench M4






#1

Align casters (#D) to the holes of the left and right side panels (#3).
Secure by using screws (#C).


#C x 4pcs
#D x 2pcs



#2

Attach dowels (#A) to each ends of the left and right side panels (#3). Align and attach left and right side panels (#3) to the dowel holes of the front panel (#1) and back panel (#2). Secure by using bolts (#B).

#A x 8pcs
#B x 8pcs






#3

Align slats (#5) to the front and back panels (#1,2). Secure by using screws (#G).

#G x 8pcs



#4

2) Align bottom panel (#4) to the rest of the trundle.
Secure by using screws (#G).

#E x 2pcs
#F x 2pcs
#G x 24pcs

1) Align knobs (#F) to the
holes of the front panel.
Secure by using bolts (#E)
from the inside.

