

Assembly instruction sheet

HT-5203

| | |
|-----------------|---|
| <p>1</p> | <p>2</p> <p>Remove and dispose protective cover</p> |
| <p>3</p> | <p>4</p> |
| <p>5</p> | <p>6</p> |

| | | | | |
|----------|----------|----------|--|--|
| | <p>1</p> | <p>1</p> | <p>1</p> | <p>1</p> <p>M6*40 X 6</p> <p>A</p> |
| <p>1</p> | <p>5</p> | <p>2</p> | <p>1</p> <p>M6*25 X 2</p> <p>C</p> | <p>3</p> <p>M8*25 X 3</p> <p>B</p> |