


ASSEMBLY INSTRUCTION

Dining Table



ASSEMBLY INSTRUCTION


Please read these instructions fully before starting assembly:

1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:







Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTION

Part List

Ⓐ 	Ⓑ 
TABLE TOP (1 pc)	UPPER CROSSBAR (2 pcs)
Ⓒ 	Ⓓ 
DECORATIVE SIDE BEAM (4 pcs)	CENTRAL LEG SUPPORT FRAME (1 pc)
Ⓔ 	Ⓕ 
DECORATIVE SIDE BEAM (2 pcs)	UPPER CROSSBAR (2 pcs)
Ⓙ 	
LOWER CENTER SUPPORT BLOCK (1 pc)	

ASSEMBLY INSTRUCTION

Hardware List


①



Ø 5/16" x 40 mm

BOLT (18 pcs)

②



Ø 5/16" x 50 mm

BOLT (16 pcs)

③



Ø5/16" x 13 mm

LOCK WASHER (34 pcs)

④



Ø5/16"x19x2 mm

FLAT WASHER (12 pcs)


⑤



4 mm

ALLEN KEY (1 pc)

⑥




Ø10 x 30 mm

WOOD DOWEL (2 pcs)


ASSEMBLY INSTRUCTION

STEP 1:



2	3	5
BOLT Ø 5/16 " x 50mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm
		
② x 4	③ x 4	⑤ x 1


STEP 2:



2	3	5	6
BOLT Ø 5/16 " x 50mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm	WOOD DOWEL Ø 10 x 30mm
			
② x 4	③ x 4	⑤ x 1	⑥ x 2


ASSEMBLY INSTRUCTION

STEP 3:



1	3	5
BOLT Ø 5/16 " x 40mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm
		
① x 6	③ x 6	⑤ x 1


STEP 4:



2	3	5
BOLT Ø 5/16 " x 50mm	LOCK WASHER Ø 5/16 " x 13mm	ALLEN KEY 4 mm
		
② x 8	③ x 8	⑤ x 1


ASSEMBLY INSTRUCTION

STEP 5:



1	3	4	5
BOLT Ø 5/16 " x 40mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
			
① x 4	③ x 4	④ x 4	⑤ x 1


STEP 6:





1	3	4	5
BOLT Ø 5/16 " x 40mm	LOCK WASHER Ø 5/16 " x 13mm	FLAT WASHER Ø 5/16 " x 19x2mm	ALLEN KEY 4 mm
			
① x 8	③ x 8	④ x 8	⑤ x 1

ASSEMBLY INSTRUCTION

STEP 7:




STEP 8:





ASSEMBLY INSTRUCTION

STEP 9:






STEP 10:



ASSEMBLY INSTRUCTION

STEP 11:



ASSEMBLY INSTRUCTION

COMPLETE

