

***DeckTok***


# **USER MANUAL**

Smart Landscape Spotlights

# What You Get

| ITEM               | QUANTITY |
|--------------------|----------|
| Power Adapter      | 1        |
| Control Box        | 1        |
| Lamp Body          | 2        |
| Ground Stake       | 2        |
| M5×10mm Screw      | 2        |
| Hex Key            | 1        |
| M5×25mm Screw      | 2        |
| Anchor             | 2        |
| Waterproof End Cap | 1        |
| User Manual        | 1        |

## At a Glance



- ① Spotlights
- ② Control Box
  - Press once to switch modes.
  - Press twice to power on/off.
  - Long press for 5 seconds light flashing in connection nextwork mode.
- ③ Power Adapter
- ④ Waterproof End Cap

# Installing Your Device


## Method One: Inserting into the Ground

- ① Connect each pair of Lamp Body and Ground Stake using M5×10mm screws and the Hex Key. Secure the Waterproof Connector Caps for each connection.

**\*Note:** Please ensure that the spotlights are connected securely and install the waterproof end cap on the last spotlight.

- ② Connect the Spotlights to the Control Box and the Adapter.
- ③ Before inserting them into the ground, plug in a power adapter to ensure all lights illuminate properly.
- ④ Position the ground stake firmly into the ground at your desired locations.

### You'll need



Lamp Body x2



M5×10mm Screw x2




Ground Stake x2



Hex Key x1




Waterproof End Cap x1



## Method Two: Mounting on Walls

- ① Drill a 7mm hole on the wall at your desired position. The distance between two holes should be at least 2 inches.
- ② Insert the Anchor into the hole.
- ③ Mount the Lamp Body onto the wall using M5×25mm Screws. Tighten the screws securely to fix the connection.

### You'll need



Lamp Body x2



M5×25mm Screw x2








Anchor x2



Hex Key x1



Waterproof End Cap x1



# Setting Up The System

1. Download the Decktok App from App Store for iPhones / Google Play for Android smartphones.



2. Connect to a WiFi supporting 2.4GHz and enable your smartphone's Bluetooth.
3. Press the on/off button on the control box for 5 seconds. When the light flashes, you can open the App.
4. On App home page, tap "Add Device" or tap "+" icon at the upper right corner and allow it to search for the spotlight device.
5. Wait for the device icon to appear. Tap the device icon and follow the on-screen instructions to complete pairing.

## Specifications

|                     |                                                         |
|---------------------|---------------------------------------------------------|
| Adapter Input       | AC 100-240V                                             |
| Power Input         | 27V / 0.88A                                             |
| Length              | 27.17FT (8.28M)                                         |
| Light Color         | RGBWW                                                   |
| Waterproof          | Light: IP65<br>Control Box: IP65<br>Power Adapter: IP44 |
| Wireless Protocol   | 2.4GHz Wi-Fi + Bluetooth                                |
| Working Temperature | -4°F-104°F                                              |

## Notice

- The product is for outdoor use only.
- Tighten up all the waterproof connector caps before use.
- Do not submerge the product in water or other liquids.
- Do not expose it to splashing or dripping water.
- Do not install the product near heat sources or in damp locations.
- Use the product with the provided power adapter only. Using unauthorized adapters may be dangerous.
- Be careful with the sharp ground stakes of the product.
- The recommended temperature range for devices and accessories is -20°C to 40°C (-4°F to 104°F) .
- Do not allow children to install this product.
- This product is not a toy. Children and the disabled should use it under adult supervision.

## Troubleshooting

### 1.Unable to connect to the App

- Ensure the device is powered on.
- Check if Bluetooth is enabled on your phone.
- Make sure your phone is connected to a 2.4GHz Wi-Fi network.
- If not, set the router to 2.4GHz and then reset it.

Long-press the control box button for five seconds until the light flashing in connection nextwork mode.

### 2. Some lights do not glow

- Unplug the adapter and plug it back in.
- If the issue persists, please contact DeckTok's official customer service.

## Customer Service

Warranty: 12-month Limited Warranty

 [www.decktok.com](http://www.decktok.com)

 [info@decktok.com](mailto:info@decktok.com)

