

2.4G DC Fan Lamp Controller Specifications

Product Introduction:

This product uses 2.4G wireless digital remote control technology, remote control one-to-one control, simple and convenient operation, strong anti-interference ability.

Technical Parameters:

Model: .4G AC fan light controller

Wall switch sequence:

full light/white light/yellow light

Input voltage:

AC100V – 130V 60Hz

Output voltage: DC70–110V

LED output power: 25–36 W

Motor rated power: <25W


Wind speed: 1 – 6 gears

Timing: 1 hour / 2 hours

Receiving method: RF2.4G

Remote control distance: 8–20 meters

Remote control battery: No. 7 1.5V X2




Remote control matching code:

Turn on the power and Press and hold the light pairing key within 5 seconds of the light on, When you hear a beep or a light flashes, the code match is successful. If you need to match the code a second time, you need to wait 30 seconds before turning on the power and repeat the above operation.

CAUTION:




The electronic switch is not an isolated product and needs to be operated by professional personnel during installation.








The electronic switch is triggered by the remote control, and the wireless frequency of the remote control transmitter is 2.4GHz.














APP operation



1. Download the APP  scan the QR code → open the browser → select the version to download
2. Open the APP → select a room → Click on  → select "fan light" → enter the equipment name (such as fan light) → OK
3. Click on  enter

-  1. Language (Chinese and English can be selected)
-  2. Scan (scan the other party's QR code to share device control)
-  3. My QR code (you can share it with the other party)
-  4. Room management (room name can be added)
-  5. Instructions (Choose the second interface fan light, instructions for using various symbols of the device)
-  6. Check for updates
-  7. Feedbackpoint to enter

APP button function description:

-  Code matching button (click this button within 5 seconds of turning on the light, such as the light source flashing or the buzzer "di", it proves that the pairing code is successful; if the pairing code fails, repeat this operation).
-  After clicking, you can choose a time to turn off the device regularly.
-  After clicking, the wind blown by the fan is like the wind in nature.
-  The wind blown by the fan after clicking is suitable for sleep.
-  After clicking, the fan will rotate in the reverse direction.
-  Click to change the direction of the wind.
-  After clicking, the fan will rotate forward.
-  After clicking, the white light and yellow light will light up at the same time, but the brightness is only 10% of the maximum brightness.
-  After clicking, the white light and yellow light will light up at the same time, and the brightness is the maximum brightness.
-  After clicking, only the yellow light will light up, and the brightness is the maximum brightness.
-  After clicking, only the white light will light up, and the brightness is the maximum brightness.

1. Scan the QR code to download the Tmall Genie app.



2. Distribution network for Tmall Spirit.

3. Connect to Tmall Fairy: Let Tmall Fairy approach the lamp to be connected, turn on the lamp, say to Tmall Fairy, "Hello Tmall. Found the device", and then complete the connection according to the Tmall Fairy prompt.

4. Tmall Genie cannot find the device handling method.

Each lamp can only be connected to one Tmall Fairy at the same time. If you want to connect to another Tmall Fairy, you need to unbind the lamp on the Tmall Fairy app or restore the lamp to factory settings.

There are several ways to restore factory settings:

1. Enter the eraser symbol in the upper right corner of the interface through the 2.4G APP and press this symbol within 5 seconds of turning on the light.
2. Press and hold the fan stop key to turn on the light and clear the code to restore the factory settings.
3. Switch on and off the light for ten consecutive times at a time, and the source will flash when the light is turned on for the tenth time to restore the factory settings.
4. Unbind the lamp on the Tmall Genie app, and the lamp will flash or the buzzer will sound when the factory settings are restored.

5. Operation instructions for Tmall Genie: (2-6 only supports fan lights with dimming and color adjustment. XX represents locations, such as living room, dining room, bedroom, etc. If no location is set, please omit it).

Lamp command:

1. Turn on/off the XX lamp.
2. Adjust the brightness of XX lamp to the brightest/darkest.
3. Adjust the brightness of XX lamp to (0-100).
4. Adjust the color temperature of XX lamp to (0-100). 0 is yellow light, 100 is white light, and 50 is neutral light
5. Adjust the color temperature of XX lamp to warm/cool color, warm/cold light.
6. Turn the lights on/ashore a bit.

Fan command:

1. Turning on/off the XX fan
2. Set the XX fan to 1/2/3/4/5/6 gear
3. Set the XX fan to forward/reverse rotation
4. Adjust the XX fan to 360 degrees and shake the head

The background command of Tmall Genie is temporarily unavailable (natural wind and sleep wind functions). This function is available on the 2.4G APP.