




Printer Stand Installation Steps







Step 1: Before installing the wheel, keep the wheel in a locked state, then align the wheel with the hole and screw it up



Step 2: Use type A screws to connect three connecting rods.



Step 3: Use type B screws to connect the three plates to the iron pipe.



Step 4: Raise the handle of the wheel, keep it unlocked, and move it anywhere