


ASSEMBLY INSTRUCTIONS

24 INCH BATH VANITY (COMBO)

SKU: N725P499706






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not Included)



(Not Included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Before Installation







Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- . We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.
- . Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions











		Insert Cam Bolt into hole as shown in diagram A.	
		Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.	
		Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - VANITY




Identifying the Hardware—Identify the hardware using the illustrations below.

Part List - N725P499706

1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Mid Panel - 1pc		Bottom Panel - 1pc
5		6	
	Top Bar Front - 1pc		Mid Bar Front - 1pc
7		8	
	Top Rear Panel - 1pc		Mid Rear Panel - 1pc
9		10	
	Bottom Rear Panel - 1pc		Adjustable Shelf - 1pc


Part List - N725P499706

11




Cabinet Foot - 4pcs

12




Tip-Out Drawer Face - 1pc

13



Tip-Out Drawer - 1pc

14




Door - 1pc

15




Door Side Panel (L) - 1pc

16




Door Side Panel (R) - 1pc

17




Door Mid Panel - 2pcs

18




Round Bar - 2pcs

19



Drawer Face - 3pcs


20



Drawer Back Panel - 3pcs


Part List - N725P499706

21




Drawer Side Panel (L) - 3pcs

22




Drawer Side Panel (R) - 3pcs

23












Bottom Drawer Panel - 3pcs

24




Sink - 1pc

Hardware List- N725P499706










A  ø6x35mm	B  ø14.5x9.5mm	C  ø8xø4x32mm
Three in one bolts (39pcs)	Three in one lock (39pcs)	Round head screw(12pcs)
D  ø8xø4x25mm	E  Damping hinge (2pcs)	F  ø7xø3.5x15mm
Round head screw (4pcs)	Damping hinge (2pcs)	Flat head screw (12pcs)
G  ø8x30mm	H  ø6x30mm	I  128x18X23mm
Wood dowel (46pcs)	Wood dowel (12pcs)	Handle (1pc)
J  Knob(4pcs)	K  ø5/32"x25mm	L  ø5/32"x35mm
Knob(4pcs)	Handle screw (5pcs)	Handle screw (1pc)
M  Hinge(1pc)	N  41x28x15mm	O  ø6xø3x12mm
Hinge(1pc)	Rotary Hinge (2pcs)	Round head screw (8pcs)
P  ø1/4"x28mm	Q  ø5/16"x30mm	R  ø5/16"x16x1mm
Hex-Head bolts(2pcs)	Hex-Head bolts(4pcs)	Washer(6pcs)
S  Shelf Pin (4pcs)	T  4mm	U  Anti fall hardware (2sets)
Shelf Pin (4pcs)	Allen key(1pc)	Anti fall hardware (2sets)

STEP: 1

A




39PCS






19

19

19




14





STEP: 2

Q	R	G	T
			
4PCS	4PCS	8PCS	1PC





STEP: 3


D	N	O	J	L
				
2PCS	2PCS	4PCS	1PC	1PC




STEP: 4




B		G		D	
	1PC		2PCS		2PCS




STEP: 5




P		R		B		G		T	
	1PC		1PC		5PCS		8PCS		1PC




STEP: 6

P	R	B	G	T
				
1PC	1PC	5PCS	8PCS	1PC







STEP: 7

B	G
	
8PCS	8PCS



STEP: 8




M	O
	
1PC	4PCS




STEP: 9



S

4PCS




STEP: 10

B		G	
8PCS		12PCS	




STEP: 11




E	F
	
2PCS	4PCS


STEP: 12




I	K	F
		
1PC	2PCS	8PCS




Use the screws to adjust up or down




Use the screws to permanent





Use the screws to adjust left or right






Use the screws to adjust in or out




STEP: 13

B		H		C		J		K	
12PCS		12PCS		12PCS		3PCS		3PCS	





x3

STEP: 14




STEP: 15





STEP: 16

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 17



HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

