


Assembly Instructions


Parcel Locker

Precautions:












1. It is strongly recommended to wear protective gloves during assembly to prevent potential hand injuries.
2. Please follow the installation directions and sequence in the instruction manual precisely. This ensures each step is completed correctly.
3. Only tighten screws after successfully assembling two or more parts. Premature tightening may cause misalignment, necessitating disassembly and reassembly.
4. Carefully verify and correctly position all components to avoid unnecessary complications during assembly.
5. If you encounter any issues during the assembly process, promptly consult the instruction manual or contact customer support.
6. We suggest performing the assembly in a spacious, well-lit area to ensure sufficient room for maneuvering.

We appreciate your patience in reading these instructions. We wish you a smooth assembly process and hope you enjoy using your new parcel locker!














Part list

A  x 1	B  x 1	C  x 1	D  x 1
E  x 1	F  x 1	G  x 1	H  x 1
I  x 1	J  x 1	K  x 1	


Hardware list

1  M6*15 x 2	2  st5.0*12 x 33	3  x 2	4  x 1	5  x 1	6  x 1
7  x 1	8  x 1	9  x 1	10  x 2	11  x 1	


Step 1




ⓔ x 1




⑥ x 1



⑦ x 1




⑧ x 1






⑨ x 1



⑩ x 2




⑤ x 1




E'


Step 2



Ⓒ x 1




Ⓘ x 1






① x 2



③ x 2




④ x 1




GI


Step 3




Ⓐ x 1




Ⓑ x 1




Ⓙ x 1




② x 8




⑤ x 1




Step 4






③ x 1




② x 2




⑤ x 1




Step 5




② x 8






⑤ x 1




Step 6




ⓕ x 1




Step 7








Ⓚ x 1




② x 9




⑤ x 1




Step 8








① D x 1



② 2 x 4




⑤ 5 x 1




Step 9


GI




Step 10




Ⓜ x 1






② x 2



⑤ x 1





Step 11




1. Initial Password 0-0-0


You need to adjust the password to 0-0-0 when you open it for the first time.




2. Setting Code



Control button from A to B position




Toggle adjustment code









Control button back to position A

3. Find Your Code

⑪ x 1



Insert the code search card as shown in the figure,
and toggle the digits one by one until it stops, it is the correct code.



Scan for Password Reset Demo!

Additionally, the installation video is
available on our product page.

If you are unable to access the link,
please contact us through your order, and
we will send the video to you directly.