

FOUNTAIN - INSTRUCTION MANUAL -



- WIDTH: 17.71 INCH
- HEIGHT: 28.74 INCH
- DEPTH: 9.65 INCH
- WEIGHT: 15.0 LBS

PRODUCT INTRODUCTION

- ▶ Water Fountains are Built To High Standards. For Technical Support, Please Check The Troubleshooting Guide In This Manual Or Contact Us Via Email.
- ▶ For Any Quality-Related Issues, Please Email Our Support Team Before Returning The Product. This Often Leads To A Faster Resolution.

ASSEMBLY INSTRUCTIONS

STEP 1

Unpack the box from the top.



STEP 2

Step 2: Upon unboxing, verify all included accessories.

Accessories include: water pump, transformer, back panel, user manual, pebbles, storage bag, gloves.



STEP 3

Align the 2-pin connector, Push until fully seated, Tighten the waterproof nut firmly.



STEP 4

Secure the back panel in place, Connect the pump's power.

Note: 1 Socket Required.



ASSEMBLY INSTRUCTIONS

STEP 5

Fountain operating normally. Both water flow and lights.

ELECTRICAL SAFETY

- The transformer will get hot during use, which is normal.
- To prevent pump damage, please to add water promptly to avoid long time
- We recommend using a Residual Current Device (GFI) Ground Fault Interrupter when connecting the fountain to the electric supply (available from DIY stores).

REPAIR & MAINTENANCE

Fountain Care Guidelines

- Winter Care: Bring Indoors if Possible (e.g., garage or shed)
- If freezing is a concern, drain all water to prevent damage.

Fountain Cleaning Tips

To Empty the Fountain of Water for Cleaning or for Winter Care:

- **For smaller fountains,** invert and let water pour away for cleaning
- **For larger fountains,** use siphon pipe for water removal.
- Always power off before cleaning or maintaining the fountain or pump.
- **Note:** Stains may be present, This does not imply the fountain is second-hand. The testing water may not dry before repacking, causing stains upon opening the package.