
furniturebox

# LORENZO

## Dining Chairs

### Assembly Guide



furniturebox

**IMPORTANT**: please read these instructions fully before starting assembly



SAFETY AND CARE ADVICE



NO POWER TOOLS

- Check you have all the components and tools listed
- Remove all fittings from their bags and separate into groups
- We do not recommend use of power tools - this could damage the unit. Only use hand screwdrivers and Allen keys
- Keep children and animals away from the work area, small parts could cause choking if swallowed
- Make sure you have enough space to lay out the parts before starting
- Assemble the item as close to its final position (same room) as possible
- Do not over tighten the nuts to avoid damage to the threads
- Only clean using a damp cloth and mild detergent. Do not use bleach or abrasive cleaners
- Do not allow children to climb or play on this product
- From time to time, check there are no loose screws in this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre
- Unless otherwise stated, this product is designed for domestic use and is not certified for commercial or contract settings.

furniturebox


## IMPORTANT INFORMATION

30 Minute Build

Two Person Build

Max Weight Capacity 120kg


**Note**: Assembly estimates are approximate and can differ based on the specific environment and user experience.

| Label | Part Name | Drawing | Quantity |
|---|---|---|---|
| 1 | Back Rest |  | 1 |
| 2 | Leg Frame |  | 1 |
| 3 | Seat Pad |  | 1 |

furniturebox

## WHAT'S IN THE BOX

**Note**: the quantities are the correct amount to complete the assembly. In some cases more fixings may be supplied than are required.

| Label | Part Name | Drawing | Size (mm) | Quantity |
|---|---|---|---|---|
| A | Allen Screw |  | M8 x 20 | 4 |
| B | Metal Washer |  | M8 x 22 | 4 |
| C | Allen Screw |  | M6 x 20 | 4 |
| D | Flat Washer |  | M6 x 16 | 4 |
| E | Allen Key |  | M6 | 1 |
| F | Allen Key |  | M5 | 1 |
| G | Spring Washer |  | M8 x 12 | 4 |
| H | Spring Washer |  | M6 x 10 | 4 |

**Please note, the fixings above are for a single chair.**

furniturebox


Note:

- Use a clear, flat surface to avoid bumps or scratches before assembling.
- Insert all fixings loosely at first to allow for alignment; only tighten them once everything is properly positioned, as some adjustment may be required.
- Avoid over-tightening, as this may damage the parts.
- Seek assistance when moving large or heavy parts

## STEP 1

Place the leg frame [2] on the floor.

Insert backrest [1] into the leg frame [2] and secure using 4x metal washer [B], 4x Spring washer [G] and 4x Allen screw [A]. To allow for alignment, partially tighten the fixings with Allen Key [E]





**NOTE**: Insert ALL screws loosely, only fully tighten when instructed to do so. In the event of miss-alignment or chair wobbling, please untighten screws, realign and re-tighten.

## STEP 2

Place seat pad [3] upside down onto a clear flat surface.


Carefully align the leg frame [2] onto the seat pad [3] and secure using 4x flat washer [D], 4x spring washer [H] and 4x Allen screw [C].
To allow for alignment, partially tighten the fixings with Allen Key [F]



furniturebox

## STEP 3

Carefully, and with help, flip the chair upright on to the legs.
Apply weight to the chair to allow the legs to level.
Fully tighten All fixings.




## STEP 4

Check the stability.
Your Chair is now ready to use!

## STEP 5

Repeat the assembly process for any subsequent chairs.

**Please ensure any and all fixings and fittings are FULLY tightened before using this product**

# our 2 year GUARANTEE

Our products come with a 2 year guarantee, giving you extra peace of mind when shopping with us!

## What the guarantee covers

**PRE-INSERTED FIXINGS**
e.g. loose metal threads

**FAULTY JOINTS**
e.g. legs bending

**EXTERNAL FIXING FAULTS**
e.g. metal discs removing from table top

**STRUCTURAL INTEGRITY**
e.g. the frame of the product

## Activate your Guarantee

Scan the QR code to read the full guarantee online and register your product. It only takes a moment to fill out.
**Or visit: furniturebox.co.uk/our-guarantee**

Furniturebox Unit 6, Indurent Park Chippenham, Clanville Way, Chippenham, SN15 5BD, UK
**Telephone:** 01747 863 333 **Email:** sales@furniturebox.co.uk