

HOW TO CONTRACT YOUR DINING TABLE

Follow these steps to safely and efficiently retract your extended dining table back into its compact shape.



STEP 1: Unlock the Tabletop

Release all security latches located beneath the tabletop. The two main tabletop halves are now loose and can be moved freely.

STEP 2: Fold the Upper Leaf

Locate the inner Panel #4 (the first leaf visible after separating the table, positioned above the metal hook). Fold this panel in half toward the opposite side.

