


Label	Picture	Description
A		Chair Back Rest x1
B		Chair Seat x1
C1		Left x1 Chair Arm Rest
C2		Right x1 Chair Arm Rest
D1		Left x1 Connecting Bracket
D2		Right x1 Connecting Bracket
E		Chair Base x1
F		Five Star Metal Leg x1
G		Ottoman Cushion x1
H		Ottoman Base x1
I		Four Star Metal Leg x1

Label	Picture	Description
J		Hexagon Wrench x1
K		Transparent Gasket x1
L		Chair Washer Φ40*2 x1
M		Hexagonal Screw M8*16 x9
N		Hexagonal Screw M6*25 x12
O		Chair Washer Φ18*1.5 x9
P		Spare part: Four Star Foot Nail x1
Q		Spare part: Five Star Foot Nail x1


1 Five star metal leg central hole along with chair base rod, press and rotate it down to the end until tighten.



2 Put the Five star metal leg upside down, then fix the rod with screw and washer provided



3 Install the chair base component to chair seat, please notice to put rubber pad before fixing the chair base under the chair seat.




4 Fix chair base and chair seat with screws.



5 Install the chair back rest and seat with the connecting bracket, pre install the left and right brackets, and be careful not to fix the screws



7 Install arm rest on both side




9 For the installation of the ottoman, use rubber pads to protect the bottom plate.



11 Insert the four-star leg down into the rod till tighten, Refer step 4 in installation for ottoman setup.



6 After adjusting the angle of the chair, fix the connecting back rest



8 Tighten the arm rest with screws underneath.



10 Refer to step 3 and 4 installation for ottoman base component setup.



12 Follow the above steps and you will get a perfect recliner.

