


MANUAL DESK RISER

OPERATING INSTRUCTIONS



FEATURES

• PNEUMATIC HEIGHT ADJUSTMENT

Pull levers (1) up to raise or lower desk riser. Release levers (1) to lock into position.

NOTE: Be careful when lowering, keep hands on levers to avoid pinching fingers.

WARNING

1. Use this product for its intended purpose.
2. Do not sit or stand on this product.
3. Do not use unless all fasteners are secured. At least every six months, check all connections to ensure they are tight.
4. Do not modify this product in any way.
5. If any parts are missing, broken, damaged or worn, stop use of the chair until repairs are made using factory authorized parts.
6. Dispose of packing material properly.
7. Failure to follow these warnings could result in serious injury.

WARNING

1. Use this product only one person at a time.
2. Do not use this chair unless all bolts screws and knobs are securely tightened.
3. Check that all bolts screws and knobs are tight every three months or as needed.
4. Do not overturn back tilt knob when decreasing tension.
5. Dispose of packing material properly. Do not use plastic cover as head covering. It may cause suffocation.
6. Do not use chair as a stepladder.
7. Use this chair for its intended purpose only.
8. Use mild detergent only for cleaning.

All chairs meet or exceed ANSI BIFMA standards.