

SECURITY MAJOR SAVE WORRY

modern stylish Bright lights at home




PRODUCT MANUAL

Falt/Sloped Ceiling Available

Cable length (Adjustable)

118in/300cm

11.8in



31.5in

23.6in

19.7in

15.7in


11.8in

7.9in



Bulb Wattage: 104W
Voltage:110v

press this button canadjust
the height of chandelier or
DIY the shape you want



Installation of sloping ceiling

31.49in

23.62in

11.81in

23.62in

15.74in

15.74in


23.62in

11.81in

Total length 157.48in





 Cold Light(6000K)

 Natural Light(4000K)

 Warm Light (3000K)

Color Temperature
Adjustable 3000K-6000K



Brightness Dimming
Range from 10% to100%



1

SIMPLE INSTALLATION OF LIGHTING FIXTURES ONLY REQUIRES THE FOLLOWING STEPS




1



Open the packaging of the lighting fixture.

2



Tear open the packaging film and remove the cross iron frame and remote control.

3



We have arranged all the suspension cables properly. You do not need to rearrange the suspension cables.


4




Press and hold the locking pin to adjust the length of the suspension wire.



5
open the packaging and install the cross iron frame separately on the ceiling.



6
All the wires of the chandelier have been connected, just connect the three wires of the chandelier to your ceiling wires (grounding wire, red live wire, blue zero wire)




7
Fix the ceiling of the pendant lamp on the cross iron frame to complete the installation of the lamp.

- Please wear gloves when installing. If there are stains and sweat stains on the hardware, they should be removed in time; With grounding symbol (⊕) Of the lighting, The reliable and permanent grounding of grounding wire must be ensured during installation.
- Fixed lamps must be fixed firmly when installing to ensure that the medium installed can bear the weight of the lamp body. After installation, pull the lamp with 5 times the weight of the lamp body for 3 times to ensure that the lamp will not fall.

2

REMOTE CONTROL INSTRUCTIONS



Attention: When the circled lights are out of sync, if you receive the lights and the wall switch is out of sync, you can use the remote control to first press the small night light. After the light turns into a small night light, use the remote control to press the dimming button again to synchronize.

Safety factors are fully considered in the design of the product, but improper installation and use may cause unnecessary loss and injury. For your safety and better use of this product, please read the instructions carefully before use and operate in strict accordance with the regulations!

- The power supply of this product is dedicated to AC110–220V or AC110V. Please refer to the label on the power supply box for specific voltage
- Please do not install it directly above the heater, open fire, gas and other high-temperature objects; do not install it in the steam room or in the wet environment such as the ceiling with wet lime;
- Please cut off the power supply before replacing the light source or removing the lamp cover and operate after the lamp is completely cooled. Do not use wet hands or live operation! it is not allowed to dismantle or refit the lamps at will.
- The high heat generated during the use of the lamp may cause danger.
- Do not place inflammable materials around the lamp, and do not touch the light source and lampshade directly by hand;
- In the process of using lamps and lanterns, if there is any abnormal situation, stop using immediately, cut off the power supply, and ask professional technicians for maintenance.
- Please entrust professional qualified personnel to install lamps.