


MODEL: IG30101S-W



OWNER'S MANUAL

Patio Privacy Screen

TABLE OF CONTENTS

ASSEMBLY GUIDE.....02

USING YOUR PRODUCT.....03

June 23, 2025

QUESTIONS?



E-mail: support@modernshade.org



Toll Free Number: 1-888-666-3070









Mon-Fri: 9:00 AM - 5:00 PM PST.



CONTACT CUSTOMER SUPPORT BEFORE RETURNING PRODUCT TO RETAILER.

ASSEMBLY GUIDE

PARTS LIST

A1 Post 1 (2 pieces) 	A2 Post 2 (4 pieces) 	A3 Post 3 (2 pieces) 	B1 Foot Base 1 (2 pieces) 	B2 Foot Base 2 (2 pieces) 	C Screen (4 pieces) 
P0010008102	P0010008202	P0010008302	P0030001102	P0030001202	P0150001102
D1 Connector 1 (6 pieces) 	D2 Connector 2 (4 pieces) 	D3 Connector 3 (3 pieces) 			
P0060010702	P0060010802	P0060010902			

HARDWARE

AA Bolt M6*12 (61+4 pieces) 	BB M6 Flat washer (61+4 pieces) 	CC M6 Allen Key (1 pieces) 	DD Stake $\Phi 8 \times 180\text{mm}$ (4 pieces) 	EE Concrete Anchor M6*60 (4 pieces) 
H0008008195	H0008008196	H0008008133	H0008008199	H0008008095

IMPORTANT:

This instruction manual contains important information necessary for the proper assembly and safe use of the product.

Read and follow all warnings and instructions before assembling and using the product.

Follow all warnings and instructions when using the product.

Keep this manual for future reference.

Installer/Assembler: leave these instructions with the consumer.

SAFETY ALERT KEY

⚠ DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

⚠ CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

⚠ WARNING

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

NOTICE

Indicates information considered important, but not hazard-related (e.g. messages related to property damage).

ASSEMBLY INSTRUCTIONS

• Please carefully unpack each of the components and hardware. check the components against the parts list and make sure there are no missing parts. lay pieces on cardboard or a soft mat to help protect the pieces from scratches.

CAUTION


Watch for sharp edges when handling the pieces, wear gloves to avoid injury.

- For ease of assembly, it is recommended to have 3 or more people and allow enough time to completely finish the assembly. assembly can take 6-8 hours. a step-ladder is required for assembly (not included).
- Follow step by step instructions, and follow all safety warnings provided with your tools.
- DO NOT tighten screws until all the screws and washers are properly installed. Tighten screws securely, do not over tighten. product should not be used in inclement weather and high winds.

STEP 01 Align one (1) foot base **B2** on top of one (1) foot base **B1** as shown. Secure with two (2) **[AA]** bolts and two (2) **[BB]** flat washers. Repeat to make a second assembly.

[AA] x 4


[BB] x 4



STEP 02 Align the bottom two holes of post **A3** to foot base **B2**. Secure with two (2) **[AA]** bolts and two (2) **[BB]** flat washers. Repeat to make a second assembly.

[AA] x 4


[BB] x 4



Outdoor Structure anchoring guide for anchoring Product to wood or concrete: If step 8, on page 6 in the assembly instructions is not properly completed, this will void the warranty.




WARNING! If your Product is not properly anchored, damage could occur. It is highly recommended for maximum safety that you mount and secure to wood or concrete footers. This is far better and safer than using ground stakes. The following are some examples of how to mount the structure to wood or concrete surfaces. Refer to local building codes or consider consulting a licensed contractor for assistance in the anchoring of this product.



Anchors should be drilled into joists or reinforced blocking (not only deck boards).



Recommended Hardware:
Expansion Bolt



Pre-drill holes for appropriately sized concrete anchors



Recommended Hardware:
Expansion Bolt

If digging for foundation, please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines. Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

CAUTION

DO NOT climb or walk on roof for any reason.

- Our components are intended for privacy, decorative and ornamental use only.
- Product is NOT INTENDED for the following:
 - A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
 - As load bearing support for a building, structure, heavy objects or swings.
 - Used in structures that trap wind, rain or snow that would create extra load on the product.
 - Accumulated snow must be removed from roof.
 - DO NOT climb or walk on roof for any reason.

LIMITED WARRANTY

We warrants this product against defects in materials and workmanship for a period of one (1) year from the original date of purchase. To the extent any such defects occur, our products will send the appropriate replacement part (s) at no charge.

This warranty does not cover:

- Inspection costs or labor for replacement of any defective parts);
- Incidental or consequential damages;
- Cosmetic defects which DO NOT affect performance;
- Normal wear and tear;
- Damage due to vandalism; acts of nature, including but not limited to wind, storms, hail, floods;
- Improper assembly, installation, or use;
- Discoloration or fading of the finish as a result of exposure to chemicals, spills, pool or salt water
- Corrosion/rust.

Your product has been designed for safety and quality. Any modifications made to the original product could compromise its structural integrity or function, and could lead to product failure or personal injury. As such, modifying this product voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY, and is not for commercial, contract or other non-residential purposes. Products disclaims all other representations and warranties of any kind, express or implied.

The warranty applies to the original purchaser and is non-transferable. It does not apply to purchases of display models, or when the product is sold on clearance or "as is".

We makes no warranty whatsoever in respect to accessories or parts not supplied with it. This warranty shall apply only within the boundaries of the United States of America and Canada. This warranty gives the original purchaser specific rights, and the original purchaser may also have other rights, which vary from state to state.

