


Curio Cabinet





Instruction Manual

Read Before Assembly

The instruction booklet contains **IMPORTANT** safety information. Please read it in full and keep it for future reference.





WARNING!



- Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.
- Different wall materials requires different type of wall anchors or screws. Use a suitable wall anchors or screws for your specific wall in order to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of device to use, please contact us or local hardware store and seek professional advice.
- Only place items that is within the recommended size and weight limit of the furniture.
- Items placed onto the furniture must be resting on a support surface without hanging over the edges.
- Climbing on, stepping on, or placing overweighted objects on the product may cause property damage and / or injuries.



CAUTION!



- Assemble the furniture on an empty carton, carpet, or rug to prevent scratches or damages.
- When assembling the furniture, keep pets and children away from the assembly area.
- Ensure the product is fully assembled before use. If you are missing any hardware or parts, do not use it until you have restored the missing parts.
- This furniture requires 2 people for assembly.
- Lay out all components and hardware separately on a flat surface and make sure that no parts are missing or damaged before assembly. Do not destroy or discard any packaging until you are certain that you have all the necessary parts for assembly.
- There are small components used in the construction of the furnitures. Loose items, plastic bags, and packaging films should be kept away from pets or children to avoid choking hazard or suffocations.
- Read this instruction manual prior to assembly and familiarize yourself with the various steps.
- Install all hardware perpendicular to the opening unless otherwise specified.
- Hand tight all hardware and careful not to over-tighten to avoid damaging the product.

Assembly Symbols



- Follow sequential order.



- Build specified number of parts.



- Flip part as indicated.



- Rotate part as indicated.



- Choose your own assembly options.



- Pay attention to the part orientation.



- Leave bolts or screws partially tighten.



- Fully tighten bolts or screws.



- Level the furniture on the ground.




Estimated Time for Assembly


100 mins




Weight Capacity Limitations are as Follows:




Tools Needed



• Philips Screwdriver




• Rubber Mallet Hammer



• Electric Drill


















Package Contents




Package Contents

CODE	DESCRIPTION	QTY
1	Upper Shelf Top Panel	1
2	Upper Shelf Bottom Panel	1
3	Bottom Shelf Top Panel	1
4	Base	1
5	Left Panel	2
6	Right Panel	2
7	Support Bar	2
8	Back Panel	4
9	Mirror Back Panel	4
10	Glass Cabinet Door	2
11	Glass Storage Shlef Panel	4

Package Contents




01 Attaching magnetic door catch



E 1x



F 4x



02 Attaching upper shelf light




F 1x



S2 1x

Short-line interface

★ Note: Tear adhesive tape apart.




03 Connecting power supply cable to the upper light




S3 1x


★ Note: Tear adhesive tape apart.



04 Attaching the touch switch




Q 1x




S4 1x

★ Note: Tear adhesive tape apart.




05 Assembling upper shelf




A 3x



C 5x




06 Attaching upper shelf top panel



A 3x



C 5x



07

Attaching mirror panels and back panels to the upper shelf



K 32x




L 2x




O 2x

★ Remove protective film on the mirror panel before installation.




08 Attaching magnetic catch to bottom shelf top panel



E 1x




F 4x



09 Attaching bottom shelf light




F 1x



S1 1x


Long-line interface

★ Note: Tear adhesive tape apart.



10


Assembling the bottom shelf



A 3x




C 5x



11

Arranging bottom shelf light power cord and attaching bottom shelf top panel.




A 3x



C 5x



R 2x



★ Note: Tear adhesive tape apart.


12

Attaching mirror panels and back panels to the bottom shelf




K 32x

★ Remove protective film on the mirror panel before installation.



13



Assembling upper shelf and bottom shelf



B 2x



C 2x




14

Inserting shelf pegs




J 20x



15


Putting on glass shelf panels

★ Caution when
handling glass
panels




16


Attaching pivot hinges and glass cabinet doors



G 2x




H 2x




I 2x

★ Caution when handling glass panels




17

Adjusting the cabinet doors' position




18

Arranging the power cord




Q 3x

★ Note: Tear adhesive tape apart.



19

Affixing the cabinet to a wall





M 2x



N 2x



O 2x



- Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.

1. Mark the drilling positions on the wall.
2. Drill pilot holes at the marked locations.
3. Insert wall anchors into the pilot holes.
4. Secure the anti-tipping strap to the wall with provided screws.

*Assembly symbols

1

2

Follow sequential order

Care and Maintenance

Thank you for your purchase. We want your item to last as long as possible.

To ensure the product gives you years of longevity, please follow the recommendations in this care and maintenance guide.



Maintenance

- Tighten all bolts and crews again within the first 2 weeks of assembly.
- Check the tightness of all bolts every 2 months and re-tighten them if they come loose.



Cleaning

- Clean the surface of the MDF (medium density fiberboard) with a lightly dampened cloth.
- A small amount of mild soap can be used if necessary.
- Dry the surface immediately after cleaning.



Attention

DO NOT use bleach or alcohol based cleaner to clean the surface.

DO NOT apply wood treatment on parts made with MDF.

MDF will swell and distort when exposed to water damage.

Make sure to dry the furniture immediately after cleaning.



Attention

The manufacturer and seller are not responsible for any and all liability relating to personal injury, property damage or losses, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification or neglect of the product.

Warranty

The products comes with a 1-year warranty from the date of delivery. Register your product on our website to enjoy out limited lifetime warranty!

After-Sale Service



Encounter any difficulties or missing parts?



We will send you replacement.



Hassle free!

No need to worry about repackaging and sending your item back.