


**A**

x1 Chair Back  
x1 Dossier De Chaise \*  
x1 Respaldo De La Silla



**B**

x1 Chair Cushion  
x1 Coussin De Chaise \*  
x1 Cojín De Silla



**C**

x2 Front Leg  
x2 Patte Avant \*  
x2 Pata Delantera



**D**

x1 Left Arm  
x1 Bras Gauche \*  
x1 Brazo Izquierdo




**E**

x1 Right Arm  
x1 Bras Droit \*  
x1 Brazo Derecho




**F**

x2 Allen Bolt Ø1/4" x 40mm \*  
x2 Vis à tête creuse hexagonale Ø1/4 " x 40mm  
x2 Perno Allen Ø1/4 " x 40mm




**G**

x8 Allen Bolt Ø1/4" x 50mm \*  
x8 Vis à tête creuse hexagonale Ø1/4 " x 50mm  
x8 Perno Allen Ø1/4 " x 50mm



**H**

x4 Allen Bolt Ø1/4" x 55mm \*  
x4 Vis à tête creuse hexagonale Ø1/4 " x 55mm  
x4 Perno Allen Ø1/4 " x 55mm



**I**

x4 Allen Bolt Ø1/4" x 76mm \*  
x4 Vis à tête creuse hexagonale Ø1/4 " x 76mm  
x4 Perno Allen Ø1/4 " x 76mm



**J**

x14 Flat Washer Ø1/4" x 19mm \*  
x14 Rondelle de plate Ø1/4 " x 19mm  
x14 Arandela plana Ø1/4 " x 19mm



**K**

x4 Flat Washer Ø1/4" x 13mm \*  
x4 Rondelle de plate Ø1/4 " x 13mm  
x4 Arandela plana Ø1/4 " x 13mm



**L**

x18 Lock Washer Ø1/4" \*  
x18 Rondelle de blocage Ø1/4 "  
x18 Arandela de seguridad Ø1/4"



**M**


x1 Allen Key 4mm \*  
x1 Clé hexagonale 4mm  
x1 Llave allen 4mm





**N**

x4 Wood Button \*  
x4 Bouton En Bois  
x4 Botón De Madera

\* Replaceable Part







REPLACEABLE PART / PARTIE REMPLACABLE / PARTE REEMPLAZABLE

ITEM NO. / ARTICLE NO. / ARTICULO NO. : P402271


DESCRIPTION / LA DESCRIPTION / DESCRIPCIÓN : UPH ARM CHAIR 2/CTN

/ CHAISE À ACCOUDOIRS CAPITONNÉE

/ SILLA DE BRAZOS TAPIZADA




x1 RP402271-BACK  
Back \*  
Le Dos  
Detrás



x1 RP402271-SEAT  
UPH Seat Frame \*  
Cadre De Siège UPH  
Estructura Del Asiento UPH




x2 RP402270-LEGF  
Front Legs \*  
Jambes Avant  
Patas Delanteras



x 1 RP402271-HWKIT  
Hardware Kit \*  
Kit de matériel  
Kit de hardware



x1 RP402271-ARMR  
Right Arm \*  
Le Bras Droit  
Brazo Derecho



x1 RP402271-ARML  
Left Arm \*  
Le Bras Gauche  
Brazo Izquierdo



x4 RP402271-WOOD PLUG  
Wood Button \*  
Bouton En Bois  
Botón De Madera

\* Replaceable Part