
# Christmas Tree Tower LED Décor with 8 Functions




## CONTENTS

Contents	1
What's Included	2
Features	3
Assembling & Using Your Product	4
Warranty	7
Notes	8

## WHAT'S INCLUDED



### FEATURES



# SPECIFICATIONS

Power Requirements	Standard Household 120V
Dimensions	
Lead Cord Length	

## **ASSEMBLING & USING YOUR PRODUCT**

Unpack all components carefully. Please check to ensure all parts have been removed from the packaging.


1. Place the Base Stand on a level surface. Insert the tapered end of an End Pole into the socket on the Base Stand. Then attach the Middle pole to the top. Twist the knob at the base clockwise to secure the pole.




 Insert the tapered end of the other End Pole into the acrylic ring attached to the LED Star and Light Strands. Attach the LED Star to the top of the assembly to cap it off.



**3.** Attach the LED String Light and Pole assembly to the Base stand assembly.



**4.** Take each string light and attach the spring hook at the end to the metal rings found around the Base Stand.



5. Congratulations, your tree is ready for display! Plug the transformer into a standard wall socket and watch the tree burst into life. Press the Function Remote button to cycle through to the desired lighting function. (See Features Pg. 3)



#### LIMITED WARRANTY INFORMATION

Thank you for choosing an our product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

#### Water Damage

Our products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage, is considered negligence, and will not be covered under this warranty. The use of "hard water," and/or caustic cleaners, can affect the painted or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of our Corporation.

#### • Paint & Color (Retention and/or Loss)

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only cover against severe or complete fading, within the first year from date of purchase, with the above exclusion.

#### Not Covered Under Warranty

The limited warranty will NOT cover cases of damages due to:

- 1. Damages caused in Transit
- 2. Inadequate care and/or neglect
- 3. Environmental and/or natural elements
- 4. Immersion in water, unless specified
- 5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.