





Assembly Instructions

Warnings: You must read this before you proceed.

Club Chair



Parts List


Label	Picture	Description	QTY
A	  A1 A2	Chair	A1-1PC A2-1PC
B	 B1	FRONT Wooden Leg	02PCS
C	 B2	Back Wooden Leg	02PCS

Hardware

Label	Picture	Description	QTY
1		Washer Ring	7

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Step 1




Position chair on its back as shown.
(**DO NOT** place on surface that can scratch or damage upholstery.)
Unzip to open and remove the 4 wooden legs.
Close pouch before assembling.

Step 2



A2




A1

Position the back rest to the back of the chair.
Pick up the back rest and insert the backrest into the back of the seat-slot - look at arrow direction as pictured.
Push the backrest fully, firmly and evenly downwards into the slot. The chair is now ready to be used.

Assembly Steps

Step 3



For installation of the legs :

Then insert the threaded stem into the threaded hole at the corner of the bottom of the chair.

Tighten leg by turning clockwise.

Repeat the same procedure to install the remaining 3 legs.

Care & Maintenance



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside. For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.