



84" Billiard Table with Table Tennis Top



Please keep this instruction manual for future reference

If you have any problems with your new product, please visit our website www.triumphsportsusa.com for the fastest expedited service possible for your replacement part ordering needs. Please have a copy of your receipt of purchase. For any technical support or warranty issues, please contact Triumph Sports USA at 1-866-815-4173 or email us at csr@triumphsportsusa.com

Limited 90-Day Triumph Sports USA, Inc. Warranty

All Triumph Sports USA, Inc. (TSU) games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any TSU game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the TSU game. This will void any and all TSU warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-866-815-4173 or email us at csr@triumphsportsusa.com.

IMPORTANT NOTICE! Please contact us before returning the product to the store.

Warnings



WARNING: Choking Hazard—Product contains small balls and small parts.
Not for children under 3 years of age.

Be sure to check out all the exciting games  **has to offer.**

Visit our web site at:

www.triumphsportsusa.com



BILLIARDS



DARTS



GAME TABLES



CASINO



OUTDOOR GAMES












DARTBOARDS

Triumph Sports USA
11327 W Lincoln Ave.
West Allis, WI 53227

www.triumphsportsusa.com

©2014 Triumph Sports USA. All Rights Reserved.

Parts List

1  CABINET FOR BILLIARD 1EA	2  LEFT LEG 2EA	3  RIGHT LEG 2EA	4  END LEG BRACE 2EA	5  SIDE LEG BRACE 2EA	6  5/16"X1-1/4" LEG BOLT 12EA
7  3/16"X1" LEG BOLT 8 EA	8  5/16"XØ19X1.5 MM WASHER 12EA	9  3/16"XØ11X1 MM WASHER 8EA	10  4x12MM WASHER HEAD SCREW 12 EA	11  TABEL TENNIS SUPPORT 2EA	12  CUE STICK 2EA
13  CHALK 2EA	14  TRIANGLE RACK 1EA	15  BILLIARD BALLS 1SET	16  LEG LEVELER 4EA	17  BRUSH 1EA	18  TABEL TENNIS PADDLE 2EA
19  TABEL TENNIS BALL 2EA	20  TABEL TENNIS NET 1EA	21  POST 2EA	22  TABEL TENNIS SURFACE HALF-A 2EA	23  T – NUT (PRE-INSTALLED) 12EA	24  SIDE POCKET CAP WITH NAIL (PRE-INSTALLED) 2EA
25  CORNER POCKET CAP WITH NAIL (PRE-INSTALLED) 4EA	26  TOP CORNER CAP (PRE-INSTALLED) 4EA	27  FABRIC POCKET (PRE-INSTALLED) 6EA	28  APRON CORNER (PRE-INSTALLED) 4EA	29  ALLEN WRENCH 1EA	30  TABEL TENNIS SURFACE HALF-B 1EA

Assembly Tips

Attention: If you are using an electric screwdriver in the assembly, please set at low torque and do not over tighten the hardware. When assembling individual parts, loosely tighten screws until all screws are inserted, then tighten completely.

Assembly Instructions

NOTE: We recommend that two adults work together to assemble this game.

Step 1


Find a clean, level place to begin the assembly of your billiard table. The table will be assembled upside down and then turned over on its legs once the assembly is completed.

Step 2

Remove all the parts from the box and verify that you have all of the parts as shown on the parts list above. Carefully cut or tear the four corners of the box so that the bottom of the box can be used as your work surface.


Step 3

Place the pre-assembled cabinet (#1) face down in your work area.



Step 4


Attach Left (#2) and Right (#3) Legs to support frame using four of Leg Bolts (#6) and four of Washers (#8) per leg. Then locate the four Leg Levelers (#16) and screw one into each Leg. See FIG.2.



Step 5


Attach End Leg Braces (#4) to Legs using three of Washer Head Screws (#10) per Leg. See FIG.3.

FIG.3



Step 6

Attach Side Leg Braces (#5) to Legs using two of Leg Bolts (#7) and two of Washers (#9) per Leg. See FIG.4.



Step 7


Now tighten all Leg and Leg Brace Bolts.

Step 8

Lift the table assembly from the floor with at least two strong adults, turn it over, and set the table assembly on its legs in the location where you want to play.


CAUTION: Two adults are recommended to flip the table as shown.

1. Lift the table off the ground.
2. Turn the table over, using caution to clear the legs as you turn.
3. Place the table on all four legs at the same time.



Step 9

Place the Table Tennis Surface Half (#22) onto the billiard surface using 2EA Table Tennis Supports (#11) Placed Underneath and insert the Net Posts (#21) and Net (#20). See FIG.5 and 5A.



YOU ARE NOW READY TO PLAY.



Table de billard de 84" avec plateau de tennis de table



Veuillez conserver ce mode d'emploi pour consultation ultérieure

Si tiene problemas con su nuevo producto, por favor visite nuestro sitio web www.triumphsportsusa.com para obtener el servicio más rápido posible a fin de satisfacer sus necesidades de pedido de repuestos. Por favor tenga a mano una copia de su recibo de compra. Para obtener servicio técnico o solucionar problemas de garantía, comuníquese con Triumph Sports USA llamando al 1-866-815-4173 o mediante correo electrónico a csr@triumphsportsusa.com

Garantie limitée de 90 jours de Triumph Sports, Inc.

Tous les jeux Triumph Sports USA, Inc. (TSU) bénéficient d'une garantie limitée de 90 jours à partir de la date d'achat. Cette garantie couvre l'acquéreur d'un jeu TSU vendu au détail contre tout défaut de matériau ou de construction pendant une période de 90 jours à compter de la date d'achat. Les seules exceptions à la garantie sont les châssis, les plateaux de table, les surfaces de jeu, les piles et les outils. Un châssis, un plateau de table ou une surface de jeu endommagé n'étant pas remplaçables, il faut rapporter le jeu au magasin. L'usure due au jeu ou à une utilisation normale n'est pas couverte par la garantie, ni l'usure ou les dommages provoqués par un usage abusif du jeu, lesquels annulent toutes les garanties TSU.

Un reçu ou une autre preuve d'achat sera exigé avant d'entamer toute exécution de garantie. Vous pouvez faire parvenir les demandes d'exécution de la garantie par courrier électronique, par courrier ou en contactant notre service à la clientèle par téléphone au : 1-866-815-4173 ou par courriel à csr@triumphsportsusa.com.

AVIS IMPORTANT! Veuillez nous contacter avant de rapporter le produit au magasin

Avertissements



AVERTISSEMENT: Risque d'étranglement. Le produit contient de petites balles et de petites pièces. Ne convient pas aux enfants de moins de 3 ans.

Ne manquez pas de consulter tous les jeux passionnants que propose Triumph Sports USA. Visitez notre site web à:

www.triumphsportsusa.com



BILLARDS



FLÉCHETTES



TABLES DE JEUX



CASINO



JEUX D'EXTÉRIEUR














CIBLES DE
FLÉCHETTES

Triumph Sports USA
11327 W Lincoln Ave.
West Allis, WI 53227

www.triumphsportsusa.com

©2014 Triumph Sports USA. Tous droits réservés.

Liste des pièces

1  CABINET FOR BILLIARD 1EA	2  LEFT LEG 2EA	3  RIGHT LEG 2EA	4  END LEG BRACE 2EA	5  SIDE LEG BRACE 2EA	6  5/16"X1-1/4" LEG BOLT 12EA
7  3/16"X1" LEG BOLT 8EA	8  5/16"XØ19X1.5 WASHER 12EA	9  3/16"XØ11X1 WASHER 8EA	10  4x12MM WASHER HEAD SCREW 12 EA	11  TABEL TENNIS SUPPORT 2EA	12  CUE STICK 2EA
13  CHALK 2EA	14  TRIANGLE RACK 1EA	15  BILLIARD BALLS 1SET	16  LEG LEVELER 4EA	17  BRUSH 1EA	18  TABEL TENNIS PADDLE 2EA
19  TABEL TENNIS BALL 2EA	20  TABEL TENNIS NET 1EA	21  POST 2EA	22  TABEL TENNIS SURFACE HALF 2EA	23  T – NUT (PRE-INSTALLED) 12EA	24  SIDE POCKET CAP WITH NAIL (PRE-INSTALLED) 2EA
25  CORNER POCKET CAP WITH NAIL (PRE-INSTALLED) 4EA	26  TOP CORNER CAP (PRE-INSTALLED) 4EA	27  FABRIC POCKET (PRE-INSTALLED) 6EA	28  APRON CORNER (PRE-INSTALLED) 4EA	29  ALLEN WRENCH 1EA	30  TABEL TENNIS SURFACE HALFB 1EA

Conseils de montage :

Attention: Si l'on utilise un tournevis électrique pour effectuer le montage, le régler sur un faible couple et ne jamais serrer excessivement, Lors du montage de pièces, serrer peu les vis jusqu'à ce qu'elles soient toutes insérées, puis serrer à fond.

Montage

REMARQUE: Le montage sera facilité s'il est effectué par deux adultes.

Étape 1


Trouver une surface plane propre pour commencer le montage de la table de billard. La table sera montée sens dessus dessous et retournée sur ses pieds une fois le montage terminé.

Étape 2

Retirer tout le contenu du carton et vérifier que toutes les pièces figurant sur la liste de pièces ci-dessus sont présentes. Couper ou déchirer soigneusement les quatre coins du carton de manière à utiliser le fond comme surface de travail.


Étape 3

Placer le châssis pré-monté (N° 1) sens dessus dessous dans la zone de travail.



Étape 4


Fixer les pieds côté gauche (N° 2) et droit (N° 3) pour soutenir le châssis à l'aide de quatre des boulons de pied (N° 6) et quatre des rondelles (N° 8) par pied. Trouver ensuite les quatre vérins (N° 16) et en visser un dans chaque pied. Voir la FIG. 2.



Étape 5


Fixer les renforts d'extrémité de piétement (N° 4) aux pieds à l'aide de trois vis à tête à embase (N° 10) par pied. Voir la fig. 3.

FIG.3



Étape 6

Fixer les renforts latéraux de piétement (N° 5) aux pieds à l'aide de deux des boulons de pied (N° 7) et de deux des rondelles (N° 9) par pied. Voir la FIG. 4.



Étape 7


Serrer maintenant tous les boulons des pieds et des renforts de pieds.

Étape 8

Soulever la table du sol, ce qui nécessite deux adultes forts, la retourner et la mettre sur ses pieds à l'emplacement choisi pour jouer.


ATTENTION : Il faut deux personnes pour retourner la table.

1. Soulever la table du sol.
2. Retourner la table en veillant à ce que les pieds ne heurtent pas le sol.
3. Placer la table sur ses quatre pieds en même temps.



Étape 9

Placer la surface de tennis de table (N° 22 en N°30) sur la surface de billard à l'aide des supports de tennis de table (N° 11) et insérer les montants du filet (N° 21) et le filet (N° 20). Voir les FIG. 5 et 5A.



LA TABLE EST PRÊTE POUR LE JEU.