
Adaptive Design, Effortless Living.

HULALA®

HOME



ITEM NO. SBHD1754

Scan for manual,
video & advice.

Adaptive Design, Effortless Living.

HULALA® HOME

If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com


MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.


NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
30 minutes.



Two Person



Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.

Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having dificulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**


For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Parts List (Carton A)

A ×1




Panel

B ×1




Left panel

C ×1




neutral board

D ×1




Right side panel

E ×1




Baseplate

F ×1




back panel

G ×1



shelf board

H ×1




shelf board

I ×1




Legs

J ×1




Left door panel

K ×1



Middle door panel


L ×1



Right door panel


Hardware List (Carton A)

1 ×4




Anti-tip component

2 ×4




Self-tapping screw
D4x20

3 ×2




Hardware pack

4 ×4




Expansion pipe
L30mm

5 ×4




Self-tapping screw
D4*40

6 ×1




Screwdriver

7 ×6+1



eccentric wheel

8 ×6+1




three in one
M6x35mm

9 ×12+2




tree top
Ø6*30

10 ×2




Half-covered door hinge
Ø35 nn

11 ×4




Internal clamp door hinge
Ø35 nn

12 ×8+1



Layer board support

13 ×30+2




Self-tapping screw
D3*16mm

14 ×36+4




Self-tapping screw
D4x16mm

15 ×8+1




Direct repair screw
Ø6.3x40mm

16 ×1




Hex wrench
M4

17 ×3




Hold hands

18 ×3+1



Pull screw
D4x28mm

19 ×6+2




Huamei Patch

ASSEMBLY INSTRUCTIONS

Step 01

Install the 3-in-1 (8) into panel (A) and tighten it with screwdriver (6).


8	x 6	M6x35	6	x 1



Step 02

Insert the tree top (9) into Panel （A）. Install side panels （B/C）, and (D)into their corresponding positions. Then insert the eccentric wheel (7) and tighten it with screwdriver (6). Cover the eccentric wheel with Ring-Ame sticker (19).


9	x 6	Ø6x30mm
7	x 6	eccentric wheel
19	x 6	Huamei Patch
6	x 1	Screwdriver



Step 03


Insert the tree top (9) into side panels (B/C), and (D). Attach the bottom panel (E) to its corresponding position. Then, insert screw (15) through the bottom panel into the corresponding holes of side panels (B/ C), and (D). Use wrench (16) to tighten.

9	x 6	Ø6x30mm
15	x 8	Ø6.3x40mm
16	x 1	M4



Step 04


nsert the middle （I） into the corresponding hole on base plate （E） and tighten it.




Step 05

Open back panel （F） and insert it into the back panel slot. Use screw (13) to go through the back panel hole and attach it to the cabinet. Tighten it with screwdriver (6).

13	x 30	D3x16mm
6	x 1	Screwdriver



Step 06





Note:
Before the next step, adjust the feet of the locker to keep it level.

Step 07

Insert shelf support (12) into the corresponding holes on side panels (B /C)and (D), then place shelves (G/H) into their respective positions and level them.



12		x 8	Layer board support






Step 08

Install hinge (10) into door panel (K), then insert screw (14) and tighten with screw-driver (6). Insert handle screw (18) through the corresponding hole in the door panel and attach handle (17), then tighten with screwdriver (6).


17	 x 1	Hold hands	18	 x1	D4x28mm	6	 x 1	Screwdriver
10	 x 2	Ø35nn	14	 x 4	M4*16mm			



Step 09

Insert screw (14) through the hinge on door panels （K） and attach it to the corresponding side panels (C). Tighten with screwdriver (6).


14	x 8	D4x16mm
6	x 1	Screwdriver



Step 10

Install hinge (11) into door panel (J/L), then insert screw (14) and tighten with screw-driver (6). Insert handle screw (18) through the corresponding hole in the door panel and attach handle (17), then tighten with screwdriver (6).


11	x 4	Ø35nn	18	x2	D4x28mm	6	x 1	Screwdriver
17	x 2	Hold hands	14	x 8	M4*16mm			




Step 11

Insert screw (14) through door panel (J) into the corresponding hole in side panel (B), and tighten it with screwdriver (6).
Insert screw (14) through door panel (L) into the corresponding hole in side panel (D), and tighten it with screwdriver (6).


14	x 16	D4x16mm
6	x 1	Screwdriver






Door Hinge Adjustment Instructions


Concealed hinges are three-way adjustable.




Horizontal by screw adjustment!




Concealed hinges are three-way adjustable.




In-and-out by loosening the hinge arm mounting screw or via cam adjustment!



Concealed hinges are three-way adjustable.




Vertical via slots in the mounting plate or via cam adjustment!



Step 12

Pass screw (2) through the anti-fall part (1) and install it in the corresponding position on panel (A), then tighten it with screwdriver (6).


2	x 4	D4x20mm
1	x 2	Anti-tip componeng
6	x 1	Screwdriver




Step 13


Install Anti-tip device (1) to the wall in this step.

5	x 4	D4x40mm	1	x 2	Anti-tip componeng
4	x 4	L30mm	6	x 1	Screwdriver






1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device 1 to the wall with screws 5.


Step 14

WARNING

Children have died from furniture tipover.
To reduce the risk of furniture tipover:
-ALWAYS install Anti-tip device provided.
-For use with televisions weighing 35 lb or less.Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
-NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.



3	x 2	Hardware pack



Adaptive Design, Effortless Living.

HULALA®
HOME

WWW.HULALAHOME.COM
Email: customerservice@hulalahome.com
Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)