












Thank you for purchasing this quality product. Be Sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.


( Note : Loosely thread all screws / bolts first. Once the Item is assembled then completely tighten.)

PARTS LIST :				HARDWARE LIST :								
S. NO.	DESCRIPTION	SKETCH	QTY	S. NO.	DESCRIPTION	SKETCH	QTY	S. NO.	DESCRIPTION	SKETCH	SIZE	QTY
1	BIG MARBLE TOP		1	1	SMALL MARBLE TOP		1	1	BOLT		6/16"	9+(1) extra
	BIG LEGS		5	2	SMALL LEGS		4	2	BOLT		6/30"	9+(1) extra
2	BIG HALF RING		1	2	SMALL FULL RING		1	3	ALLEN KEY		4 MM	1
								4	WASHER		1/2 "	9+(1) extra


STEP : 1 Fix iron legs with marble top match whole with the help of Allen Key and bolt and tighten properly.




STEP : 2 Fix iron ring with iron legs match whole with the help of Allen Key and bolt and tighten properly.




STEP : 3 Fix iron legs with marble top match whole with the help of Allen Key and bolt and tighten properly.



STEP : 4 Fix iron ring with iron legs match whole with the help of Allen Key and bolt and tighten properly.



Tip A: Sometimes the furniture will not balance because of an uneven floor surface its rests on. In that case, try adjusting the levelers found on the bottom of each foot to aid in correcting.



FINISH