


ASSEMBLY INSTRUCTIONS

30 INCH WALL CABINET WITH MIRROR






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or
missing or damaged parts please contact the seller.

Before Installation


Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- . We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.
- . Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions















Detail View - CABINET







Identifying the Hardware-Identify the hardware using the illustrations below.

Part List


1	 Top Panel - 1pc	2	 Side Panel Left - 1pc
3	 Side Panel Right - 1pc	4	 Mid Panel - 1pc
5	 Bottom Panel - 1pc	6	 Mid Panel Left - 1pc
7	 Mid Panel Right - 1pc	8	 Rear Top Bar - 1pc
9	 Connect Bar - 1pc	10	 Back Panel Left - 1pc
11	 Back Panel Right - 1pc	12	 Door Cabinet Left - 1pc
13	 Door Cabinet Right - 1pc	14	 Adjustable Shelf Left - 1pc
15	 Adjustable Shelf Right - 1pc		

Hardware List






A  ø6x35mm	B  ø14.5x12mm	C  ø10xø5x60mm
Three in one bolts (15pcs)	Three in one lock (15pcs)	Flat head screw (3pcs)
D  ø12x55mm	E 	F  ø5/32"x25mm
Plastic stopper (3pcs)	Handle (2pcs)	Handle screw (4pcs)
G 	H  ø7xø3.5x12mm	I 
Damping hinge (4pcs)	Flat head screw (24pcs)	Laminate pad(8pcs)
J  ø8x30mm	L  ø7xø3.5x15mm	
Wood dowel (24pcs)	Round head screw(2pcs)	

STEP: 1




A




15PCS





Turn over and install screw (A)





STEP: 2

B		J	
1PC		2PCS	





STEP: 3

B		J	
2PCS		4PCS	




STEP: 4


B		J	
6PCS		10PCS	




STEP: 5




STEP: 6



B		J	
6PCS		8PCS	


STEP: 7





L	
2PCS	



STEP: 8

G	H
	
4PCS	8PCS






STEP: 9

E	F	H
		
2PCS	4PCS	16PCS





STEP: 10

I

8PCS


STEP: 11


C

3PCS
D


3PCS


Draw the spacing between the walls and the No.9, punch holes in the wall, and fix the No.9 to the wall with screws.
 Note: Appropriate distance from the top of cabinet to the ground is 74.8".


STEP: 12



STEP: 13



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

