

STEP 6 Attach Panel (C) to Panel (A) by tighten the Mini Fix Bolt & Cam (1A&1B).

STEP 7

Attach Panel (C) to Panel (B) using Screw (2) as shown.



Recommended Maximum Weight



WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.

Assembly Instruction


Simple Design Bookcase

DIMENSION: 23.6"(W) x 29.8"(H) x 11.6"(D)









Customer Support

NEED HELP? For help with assembly, or if you are missing a part, please call our Customer Service.










No	Hardware List	Qty
1	Mini Fix Bolt + Cam 1A 1B	2sets
2	C/B Screw	8pcs
3	Nail Leg	2pcs
4	Insert Cap	2pcs
5	Round Leg	2pcs
6	Round Pole	4pcs

No	Parts List	Qty
Α	Top Panel	1pc
В	Shelf Panel	2pcs
С	Back Panel	2pcs




USEFUL HINTS BEFORE YOU START:

- 1. Read each step carefully before starting.
- 2. It is important that each step is performed in correct order to avoid difficulties.
- 3. Identify, sort and count the parts before assembly.
- 4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
- 5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
- 6. Using uncompatible hardware might cause damage to product.


STEP 1

Install Mini Fix Bolt (1A) and Insert Cap (4) into Panel (A), as shown.




STEP 2

Install Mini Fix Cam (1B) and Nail Leg (3) into Panel (C), as shown.




STEP 3

Attach Round Pole (6) to Insert Cap (4) and tighten it.



STEP 4

Attach Panel (B) between the Round Pole (6) and tighten it.



STEP 5

Attach another Panel (B) to the assembled unit and tighten with Round Leg (5).

