






Elite Adirondack
Adirondacks d'élite
Élite Adirondack


Assembly Instructions
instructions de montage
Instrucciones de montaje







Hardware Included
Matériel inclus
Herrajes incluidos


(38212) x8





(214212) x4



(6114) x4




(114212) x2




(9532) x1







Items Not Included
Articles non inclus
Artículos no incluidos






#2 Square Drive Bit
Embout d'entraînement carré #2
Punta cuadrada n.º 2



1 (A) x1
(B) x1
(C) x1



2 (D) x1



3 (E) x1

