


ESPRESSO FLOOR LAMP



PLEASE READ AND SAVE THESE INSTRUCTIONS:

1. REMOVE ALL PARTS AND LAY ON A FLAT SURFACE.
2. SCREW POLE (B) CLOCKWISE INTO POLE (A) TO TIGHTEN AND GET THE REMAINING SLACK OF THE POWER CORD OUT CAREFULLY FROM POINT (E).
3. SET SHADE (C) ON SOCKET (F) AND TIGHTEN CLOCKWISE WITH SOCKET RING (D) TO SECURE SHADE.



At Least 25 pounds per Pole

MAINTENANCE:

Please use a 150 watt incandescent bulb.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER PLUG.**