











WARNING!

Before assembling, please read carefully the safety instructions!

Package contents:

- Wall light
- Mounting material
- User manual

Safety Instructions:

- This product must be installed by a qualified electrician.
- Disconnect the power supply before installation or maintenance.
- Ensure the supply voltage matches the rating on the product label.
- Do not exceed the maximum wattage indicated on the fixture.
- Use only replacement bulbs of the same type and rating.
- Ensure the mounting surface can support the fixture weight.
- For indoor use only (IP20). Do not install in damp areas.
- Allow the fixture to cool before replacing bulbs.
- Do not touch the bulb with bare hands when lit.
- Keep flammable materials away from the fixture.

Bulb Replacement:

1. Switch off the power and allow the fixture to cool.
2. Remove the glass shade carefully.
3. Unscrew the old bulb and replace with a new one.
4. Reattach the glass shade and restore power.

Specifications

Voltage:	220-240V AC
Frequency:	50/60Hz
Socket:	E14
Max. Wattage:	25W per bulb
Protection:	IP20 (Indoor)
Material:	Glass + Metal