


















(D)	Montageanleitung	(GB)	Assembly instructions
(NL)	Handleiding voor de montage	(PL)	Instrukcja montażu
(TR)	Montaj talimatı	(RU)	Инструкция по монтажу
(RO)	Instrucțiunile asamblare	(CZ)	Montážní návod
(IT)	Istruzioni per il montaggio	(FR)	Instructions de montage
(SK)	Montážny návod	(HU)	Szerelési útmutató




































21 **s14** x2 




22


OTWIERANIE
OPEN




23




24




25




26




27



28



29



30

