



ASSEMBLY INSTRUCTIONS

SKU CODE: (N710P429509P)























Detail View












Part List


N710P429509P

1  Top Panel (Right) - 1pc	2  Bottom Panel (Left) - 1 pc	3  Top Panel (Left) - 1pc
4  Bottom Panel (Right) - 1pc	5  Small Side Panel (Right) - 1 pc	6  Small Side Panel (Left) - 1 pc
7  Side Panel (Right) - 1pc	8  Side Panel (Left) - 1pc	9  Center Panel - 1pc
10  Shelf - 2pcs	11  Door Panel Hinges Rail (Left & Right Side) - 2pcs	12  Door Panel Handle Rail (Left & Right Side) - 2pcs
13  Door Panel Hinges Rail (Center Left & Right Side) - 2pcs	14  Door Panel Handle Rail (Center Left & Right Side) - 2pcs	15  Door Panel Top & Bottom Rail (Center Door) - 4pcs
16  Door Panel Top & Bottom Rail (Left & Right Side) - 2pcs	17  Door Panel Top & Bottom Rail (Left & Right Side) - 2pcs	18  Rattan Door Panel (Left & Right Side) - 2pcs
19  Rattan Door Panel (Center Door) - 2pcs	20  Back Panel - 1pc	21  Back Panel - 1pc

Hardware List N710P429509P


A  Ø8*30mm Wood Dowel (36 pcs)	B  Ø8*50mm Wood Dowel (6 pcs)	C  Cam Nut (14 pcs)
D  Cam Bolt (14 pcs)	E  Ø4 x 45mm Chip Board Screw (10 pcs)	F  Ø4 x 38mm Chip Board Screw (16 pcs)
G  Ø4 x 30mm Chip Board Screw (8 pcs)	H  Ø3.5 x 16mm Chip Board Screw (82 pcs)	I  3/4" Nails (48 pcs)
J  Metal Plate (4 pcs)	K  Metal Handle (4 pcs)	L  7/8" Hydraulic Hinges (4 pcs)
M  SJ09V-90 Hydraulic Hinges (4 pcs)	N  Metal Leg (6 pcs)	O  Door Stopper (2 pcs)
P  Sticker (16 pcs)		

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !


STEP 1 :




STEP 2 :





STEP 3 :

A	B	D	H	R
				
12 PCS	2 PCS	2 PCS	1 PC	1 PC



STEP 4 :

H	R
	
1 PC	1 PC




BOTH SIDE NEED TO INSTALL STOPPER

STEP 5 :

C




2 PCS




STEP 6 :

J




2 PCS


H



8 PCS




STEP 7 :




STEP 8 :

C



10 PCS



STEP 9 :


C**2 PCS**

STEP 10 :


J**2 PCS****H****8 PCS**

STEP 11 :

E




10 PCS




STEP 12 :


I



48 PCS




STEP 13 :



H	N
24 PCS	6 PCS

REMARK!
SECURE BOTTOM PANELS WITH METAL PLATES


STEP 14 :




A
16 PCS

STEP 15 :

F




4 PCS




STEP 16 :



F




4 PCS





STEP 17 :

G	H	K	L
			
4 PCS	8 PCS	2 PCS	4 PCS




STEP 18 :


F

4 PCS




STEP 19 :




F




4 PCS



STEP 20 :



G



4 PCS

H



8 PCS

K





2 PCS

M



4 PCS




STEP 21 :

REMARK !!
COVER THE EXPOSED SCREW
(UNDER PANEL 15,16 AND 17)
WITH STICKERS (P).

P

16 PCS




STEP 22 :


H





16 PCS




Use the "waist round hole" marked with a triangle to adjust the position of the door panel (ensure that the gap between the door panel and the upper and lower panels is consistent).



Use the screw at the back end of the hinge to adjust the front and back position of the door panel (ensure that the front of the door panel is in the same plane as the upper and lower panels).



Use the screw at the front end of the hinge to adjust the left and right position of the door panel (ensure that the left and right sides of the door panel are in the same plane as the upper and lower panels).




After completing these three steps, secure the other two screws on the hinge.

STEP 23 :


H





8 PCS



Use the "waist round hole" marked with a triangle to adjust the position of the door panel (ensure that the gap between the door panel and the upper and lower panels is consistent).



Use the screw at the back end of the hinge to adjust the front and back position of the door panel (ensure that the front of the door panel is in the same plane as the upper and lower panels).



Use the screw at the front end of the hinge to adjust the left and right position of the door panel (ensure that the left and right sides of the door panel are in the same plane as the upper and lower panels).

STEP 24 :

