


# ASSEMBLY INSTRUCTIONS




# IMPORTANT REMARKS




Never climb or lean on the furniture.  
You may suffer serious accidents.



Use the packaging to cover the  
assembly area and separate  
all parts.



Identify the parts by observing the  
number printed on their edges.




## CARE INSTRUCTIONS



Wipe clean using a damp cloth and a mild cleaner.  
Do not use abrasive and chemical products.



## HANDLING




Move the piece carefully, don't drag it. Ask  
for someone else's help to do so.


# HARDWARE



Identify and separate the hardware used in the assembly. There's a label on each package identifying the parts and where to use them.



STICKER - 4x



A

COD. 0494 - 10x




B

COD. 1668 - 20x



C

COD. 8471 - 4x




D

COD. 0599 - 10x




E

COD. 3706 - 8x



F

COD. 8056 - 16X




G

COD. 9333 - 8X




H

COD. 0357 - 16X






I




# DESCRIPTION


W:53.15in H:24.02in D: 14.02in  
 W:1350mm H:610mm D: 356mm

PART	QUANTITY	DESCRIPTION	BOX
21	01	BACK PLATE	01
22	01	BASE	01
23	01	TOP BOARD	01
24	02	NICHE TOP PANEL	01
25	02	NICHE BACK PANEL	01
26	02	SIDE NICHE	01
27	02	NICHE BOTTOM	01
28	01	LONG DIVIDER	01
50	04	LEG	01




COD. 0494 <b>B</b> 	COD. 1668 <b>C</b> 	COD. 0599 <b>E</b> 	COD. 3706 <b>F</b> 
--	---	--	--


01



02




03




04





STICKER A	COD. 0494 B	COD. 0599 E	COD. 0357 I
--------------	----------------	----------------	----------------




05



06



07



Place them using pilot hole.

