


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED:

Allen Wrench (Provided, Part E)

BEFORE YOU START:

1. Check the parts against the parts list to make sure all items are present.
2. Assemble your furniture on a soft, flat surface to avoid scratching the finish.
3. **CAUTION:** Do not over tighten screws, nuts or bolts during assembly.
4. Your furniture may require occasional tightening.

INSTRUCTIONS:

1. Turn the table upside down on a clean soft surface.
2. Attach the three legs to the case using Bolt (A), Lock Washer (C), Flat Washer (D), and tighten with Allen Wrench (E) as shown in Figure 1.
3. Attach the shelf to the legs using Bolt (B), Lock Washer (C), Flat Washer (D), and tighten with Allen Wrench (E) as shown in Figure 2.
4. Attach fourth leg to Table and Shelf as in Steps 2 & 3 above.
5. Turn the table upright.

Figure 1










Figure 2



| No. | Hardware List | | Q'ty |
|-----|---|------------------------|------|
| A |  | Bolt Ø1/4 "x1-1/4 " | 4pcs |
| B |  | Bolt Ø1/4 "x5/8 " | 4pcs |
| C |  | Lock Washer Ø1/4" | 8pcs |
| D |  | Flat Washer Ø1/4"*16mm | 8pcs |
| E |  | Allen Wrench 4MM | 1pc |

Thank you for purchasing furniture