

4 Setting the milling fineness

Turn the dial clockwise for finer results.
Turn the dial anticlockwise for coarser results.



If the milling mechanism stops rotating with a very fine setting, a coarser setting must be selected.

