








Assembly Instruction





TV Stand with Solid American Cherry



Parts List



Hardware






Diagram 1.

Step 1.

Invert the Top (A) on a soft surface.

Tighten Connector Bolt (RF40084) into the Top (A), then attach Side Panels (E) by using Connector (RF40083) as per diagram 1.




Diagram 2.

Step 2.

Attach Middle Shelf (B) into the Side Panel (E) by using Screw (RF10052) as per diagram 2.




Diagram 3.

Step 3.

Attach Front Supports (F) into the unit by using L Bracket (RF50003) and Screw (RF10004) as per diagram 3.




Diagram 4.

Step 4.

Attach Back Panel (D) into the unit, (D) to (B) using Screw (RF10052), (D) to (A) using Metal Plate (RF40214) and Screw (RF10004) as per diagram 4.




Diagram 5.

Step 5.

Attach Bottom Shelf (C) into the unit by using Screw (RF10052) as per diagram 5.




Diagram 6.

Step 6.

Attach Feet (G) into the unit by using Screw (RF10034) as per diagram 4.