

LAMP ASSEMBLY INSTRUCTIONS

PART LIST:

A. Lamp base
B. Lamp shade
C. Socket
D. Harp
E. Finial





ASSEMBLY:

1. Place lamp base on a level surface. (Do not plug the lamp into any electrical socket until you have properly inserted the bulb and completed all steps).
2. Insert the harp (D) until it sits firmly on the saddle (C). Make sure it is secure.
3. Place the Shade (B) on the top of the harp (D) and tighten with the finial (E) to secure the shade in place.
4. Insert the bulb into the bulb socket (C) (bulb not included) Recommend using a 60 Max Wattage 120 Volts Bulb or less.

IMPORTANT SAFETY INSTRUCTIONS:

-These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric stock. This plug will fit in a polarized outlet only one way. If it does not fit, contact a qualified electrician.Never use with an extension cord unless the plug can be fully inserted.
- This lamp is meant for indoor use.
- Save these instruction and read the warnings carefully.

WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

CARE INSTRUCTIONS:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

Thank you for your purchase!