

ASSEMBLY INSTRUCTION

Before beginning

! Unpack all parts and hardware to ensure you have all needed components for assembly.

! Read this guide cover before beginning assembly.

! Assemble this item on a soft surface such as carpet to protect finish.


! Proper assembly of this item requires 2 people & 20 minutes to assembly.

CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners, Any liquid spilled in the table should

Be cleaned up immediately with a damp cloth.


A



B



C



HOW TO ASSEMBLY

STEP-1 Place the End Table top upside down on rug.





STEP-2 Match marking A with A,C with C respectively

STEP-3 Insert allen bolt E with spring washer G and flat washer F then tighten with allen key D.

STEP-4 Match marking B with A,C with B respectively

STEP-5 Insert allen bolt E with spring washer G and flat washer F then tighten with allen key D.

STEP-6 Turn the End Table upside down End Table is ready to use.

No.	Sketch	Description.	Size (IN)	Qty.	Ext.
D		ALLEN KEY	0.19	1	1
E		ALLEN BOLT	0.31X0.18	12	1
F		WASHER	0.35X1	12	1
G		SPRING WASHER	0.35X0.5	12	1

Tip for leveling of product:
When the product rests on an uneven floor surface
it will appear to be unbalanced. To aid in leveling, try
adjusting the levelers on the bottom of each foot.

Adjustable levelers

