

Product Name:	Mini Santa Claus Lighted Globe Holiday Decoration
SKU #:	WHHD2069

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

CARTON CONTENTS:


Description	Quantity	Sketch
Snowman	1	
Iron outer Tube	1	
Iron Inner Tube	1	
Base	1	
Ground Stakes	4	1

Before You Start

1. Decide on an appropriate location for your product, please read assembly and Instruction procedure carefully.
2. Retain the instructions for future use and save the carton for storing your decoration.


Assembly and Instruction Procedure:

Remove all packaging (i.e., cardboard or plastic) before beginning. We suggest unpacking the Santa decoration on a large cloth.




Product Name:	Mini Santa Claus Lighted Globe Holiday Decoration
SKU #:	WHHD2069


2.




3.



4.



5.



Product Name:	Mini Santa Claus Lighted Globe Holiday Decoration
SKU #:	WHHD2069



Warnings:

1. Do not place the decoration near fireplaces, candles, outdoor heaters, or other similar sources of heat.
2. Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the decoration may fall or blow into.
3. This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.

Storage:

1. Disassemble each part by reverse steps of the assembly.
2. Place the decoration back into the carton.
3. Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35°C (95°F).