


INSTALLATION AND SAFETY INSTRUCTIONS

- 1.TURN OFF POWER.
- IMPORTANT:** Before you start, NEVER attempt any work without shutting off the electricity until the work is done.
- a)Go to the main fuse, or circuit breaker, box in your home.Place the main power switch in the“OFF” position.
- b)Unscrew the fuse(s), or switch“OFF” the circuit breaker switch(s), that control the power to the fixture or room that you are working on.
- c)Place the wall switch in the "OFF" position. If the fixture to be replaced has a switch or pull chain, place it in t he“OFF" position.

- 2.Find the appropriate threaded holes on mounting strap.Assemble mounting screws into threaded holes.
- 3.Attach mounting strap to outlet box.(Screws not provided).Mounting strap can be adjusted to suit position of fixture.
- 4.Grounding instructions: (See Illus. A or B).
- A) On fixtures where mounting strap is provided with a hole and two raised dimples. Wrap ground wire from outlet box around green ground screw, and thread into hole.
- B) On fixtures where a cupped washer is provided. Attach ground wire from outlet box under cupped washer and green ground screw, and thread into mounting strap.

If fixture is provided with ground wire. Connect fixture ground wire to outlet box ground wire with wire connector. After following the above steps. Never connect ground wire to black or white power supply wires.




5.Make wire connections Reference chart below for correct connections and wire accordingly.

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)

6.Push fixture to ceiling, carefully passing mounting screws through holes in canopy.

7.Secure fixture to ceiling with knurl knobs.



APP Control Connection:

1. First download the free Carro Home app from the App Store or Google Play or scan the QR Code as below. It is advised to turn on WIFI and Bluetooth on your phone when connecting the device to the APP. More details please check below.

Note: This light needs to use 2.4Ghz wifi to work when you connecting the device, and after connecting it can use the 5Ghz or 2.4Ghz.



2. Open the Carro Home app to create your account. The account with “Carro Home” can be registered through E-mail or Mobile phone.

3. Setting up the device

① **Power on the device.**

② **Connecting the Carro Home APP for the first time: after power-on, the light will blink for 18 seconds, which means the light enters Carro Home APP connection mode.**

Note: After power on the device, please complete the APP connection within 3 minutes.

You have two ways to reset the connection:

- a. Repeat powering the light on and off in a row to cancel the previous APP connection, “On-OFF-ON-OFF-ON” (the interval should not be too short, power off the light after the light is on). If the reset is successful, the light will flash again.
- b. Remove the device directly from the APP to reset the connection.

4. Connect the device to the Carro Home app (3 ways connection):

① **Bluetooth connect (WIFI & Bluetooth on)**

- a. Press “+” button into the device list, then a window will pop up to show you some devices can be connected.
- b. Click “Go to add” (If you click “Do not add” in mistake, please see “Do not add” steps).
- c. Choose the device.
- d. Connect to your home WIFI, then back to the app and wait for connecting.

“Do not add” steps:

- a.Select “Lighting” on the sidebar menu, then select “Pendant Light” and tap next.
- b. Connect to your home WIFI and tap “Next” to wait for connecting.

② **Auto Scan (WIFI & Bluetooth on)**

- a. Press “+” button into the device list.
- b. Tap “Auto Scan” on the top.
- c. Wait for the device comes out and tap “Next”.
- d. Press “+” button to add device.
- e. Connect to your home WIFI.
- f. Wait for connecting.

③ **WIFI connect-EZ Mode (WIFI on & Bluetooth off)**

- a.Press “+” button to select "Lighting" on the sidebar menu, then select "Pendant Light" and tap next.
- b. Connect to your home WIFI (Only for 2.4Ghz).
- c. EZ Mode is set as default, just tap “Next” button to wait for the connection to complete.

5 Connect the device to the Alexa:

- a. Make sure you have connected the device to the app and working normally.
- b. Open Alexa app, go to the skill to search “Carro Home” skill.
- c. Link the skill, log in with your Carro Home app account and password, then authorize and connect with Carro Home app.
- d. Then the Alexa will find out the device automatically.

6. Connect the device to the Google Home

- a. Make sure you have connected the device to the app and working normally.
- b. Open Google Home app, Set up a device, choose “Works with Google”.
- c. Search “Carro Home”, log in with your Carro Home app account and password, then authorize and connect with Carro Home app.
- d. Then the Google Assistant will find out the device automatically.

7. Connect the device to the Siri shortcuts

- a. Make sure you have connected the device to the app and working in functional.
- b. Tap “Smart” on the main menu.
- c. Tap “+” button.
- d. Tap “launch Tap To Run”.
- e. Tap “Run the device”.
- f. Choose the device you want to control by Siri.
- g. Select the function you want to control by Siri.
- h. Then save it.
- I. Add to Siri, choose the scene you just made, Add to Siri .
- j. Enter the sentence you want to say to make the device works, Add to Siri.

Carro USA Inc.
1431 S.Baker Ave. Ontario CA 91761
Tel: 888-253-2374
www.carrohome.com | cs@carrohome.com