


ASSEMBLY INSTRUCTION



Tips

1. Customer Support

Thanks for your purchase! If your product is damaged, missing parts, or has assembly issues, contact us with clear photos of the problem. We'll provide the best solution quickly.


2. Assembly & Maintenance

Match parts to the manual's numbers. If mismatched, check the manual. First loosely align screws with pre-drilled holes, then tighten one by one. Periodically check screw tightness. Keep sharp/corrosive objects away to avoid damage or injury.

3. Assembly Help




It is recommended that two people assemble the product together.

Parts List:






Hardware List:

Note:The **P** and **E** screws look very similar, Do not mix up the **P** and **E** screws during assembly

 Ax53+2	 Bx53+2	 Cx24+2	 M4x35mm Dx45+2	 M4x12mm Ex132+6	 M4x16mm Fx22
 Gx4	 Hx4	 Ix2	 Jx2	 Kx6	 Lx11
 Mx1	 Nx18	 Ox2	 M4x14mm Px44+4		

1






Ex24



Nx8



2



Ax6



Jx2




Kx6



Px18



3



Ax5




Ex15



Nx5



4




Ax5




Ex15



Nx5



5




Bx4



Cx4



6




Bx6



Cx6



7




Bx6



Cx6




8



Cx8



9



Hx4




Px16



Ix2



10




Dx4



Px6




11





Dx2	
Mx1	
Px4	


12




Ex8		Fx4	
Gx4		Lx2	




Ax5		Bx5		Dx5			
Ex6		Nx2		Lx1		Fx2	





X8

Ax32		Bx32		Dx32	
Ex48		Nx16		Lx8	
				Fx16	

15





16



Ex16





Dx2 

Ox2 