

3-Piece Lighted Christmas Deer Installation Instructions

Do not plug the light string into an outlet until this item is fully assembled and the light strings are properly connected.

Please read the enclosed important safety instructions and cautions carefully prior to use.

Enclosed Parts

*Buck: 2 Antlers with Ears Head, Body, 4 Legs, Tail, Bow
*Doe: 2 Ears, Head, Body, 4 Legs, Tail, Bow
*Fawn: 2 Ears,
*Head, Body, 4 Legs, Tail, Bow
*3 Cotter Pins
*12 Lawn Stakes

Spare Parts

*3 Cotter Pins
*15 Plastic Ties

Instructions

1. Carefully remove item from the protective wrap, do not use a knife, to avoid damaging any of the light bulbs or parts.

2. Assemble the buck:



*Attach the 2 front legs and 2 back legs to the body by inserting the rods on the legs into the holes on the body. Then secure the front legs by inserting the hook on one of the front legs into the hole on the other front leg. Secure the back legs in the same manner.

*Insert the tail on the back.

*Attach the head onto the body by inserting the rod into the hole on the front, then insert the rod into the hole on the back, and then secure with a cotter pin.

*Attach the 2 antlers with ears onto the head by inserting the rods on the antlers into the holes on the head.

*Hang the bow on the neck.



3. Assemble the doe:


*Attach the 2 front legs and 2 back legs to the body by inserting the rods on the legs into the holes on the body. Then secure the front legs by inserting the hook on one of the front legs into the hole on the other front leg. Secure the back legs in the same manner.

*Insert the tail on the back.

*Attach the head onto the body by inserting the rod into the hole on the front, then insert the rod into the hole on the back, and then secure with a cotter pin.

*Attach the 2 ears by inserting the rods on the ears into the holes on the head.

*Hang the bow on the neck.



4. Assemble the fawn:


*Attach the 2 front legs and 2 back legs to the body by inserting the rods on the legs into the holes on the body. Then secure the front legs by inserting the hook on one of the front legs into the hole on the other front leg. Secure the back legs in the same manner.

*Insert the tail on the back.

*Attach the head onto the body by inserting the rod into the hole on the front, then insert the rod into the hole on the back, and then secure with a cotter pin.

*Attach the 2 ears by inserting the rods on the ears into the holes on the head.

*Hang the bow on the neck.



5. Connect the 3 male plugs on the deer to the 3 female plugs on the connecting wire, then turn the caps clockwise until secure.

6. Secure the item firmly into the ground by pushing the lawn stakes through the feet.


7. Connect the power adaptor on the unit to a CUL listed extension cord.



Power Plug



Connection Cord



*Thank you for purchasing our products. If you encounter difficulties in assembly, you can contact the Amazon seller team.