

standby state;

4. Code matching method: When the control box is in the code matching state, press and hold the "Head Up" and "Head Down" buttons at the same time for about 3 seconds, the buzzer will sound, and the remote control will follow the control. The box is paired successfully;
5. When the remote control and the control box are paired successfully, they can be used normally.

Key operation and function description:

1. Head up button: keep pressing the button, the head will rise. Release the button to stop running.
2. Head down button: keep pressing the button, the head down. Release the button to stop running.
3. Foot up button: keep pressing the button, the foot is up. Release the button to stop running.
4. Foot drop button: keep pressing the button, the foot drops. Release the button to stop running.
5. TV/ZG/Anti-snore: Click the button and release it, the head and feet will automatically move to the set position, and press any button during the running process to stop running.
6. FLAT button: Click the button and release it, the head and feet will automatically drop to the flat position, and press any button during the running process to stop running.

II. Other instructions:

1. When you press any button on the remote control, the backlight of the remote control will turn on for about 3 seconds and then automatically turn off.
2. The control box is designed with overload protection function, and the

overload protection current is 4.5A.

3. How to use the same remote control to control two beds at the same time:
 - ① Operate the control box of the first bed according to steps 1-4 in "Connection and Power-on". After the code is successfully matched, the control box of the first bed will be Become the "Master Control Box";
 - ② Operate the control box of the second bed according to steps 1-2 in "Connection and Power-on". When the control box of the second bed is in the matching state, press and hold "Foot Up" and "Foot Down" at the same time. "Two buttons, press and hold for about 3 seconds, the buzzer sounds, the remote control is successfully paired with the control box of the second bed, and the control box becomes the "slave control box";
 - ③ The "master control box" and "slave control box" cannot be the same control box. When the remote control and the two control boxes are paired successfully, pressing the remote control button can control two beds at the same time.

How to unpair the remote control from the control box:

One remote control unpairing of two beds: operate the control box of any bed according to steps 1-2 in "Connection and Power On", when the control box is in the pairing state, press and hold the Press the two buttons of "head up" and "head down" for about 3 seconds, when the buzzer sounds once, the remote control and the control box are successfully paired, and the other control box is automatically released from the pairing relationship.

2. Adjustment of preset memory bits:

The three preset memory positions of TV/ZG/Anti-snore are adjustable. If the customer thinks that the initial position of "TV" is unsatisfactory, he can adjust it to a comfortable position, then press and hold the "TV" button for 3 seconds, when the buzzer beeps The "TV" position will be adjusted to the current position when the device beeps once, and the adjustment method of the other two preset positions is the same.

3. The method of restoring the factory setting of the preset memory bit:

If you want to restore the three preset memory positions to the factory