

Assembly Instruction

TEA TABLE

⚠ WARNING: To avoid serious personal injury:


- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. Bob's furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

PART LIST			
No.		PART DESC	QTY
A		END TABLE ROUND TOP FRAME	2
B		END TABLE CENTER LEG	2
C		END TABLE SIDE LEG	4
D		END TABLE GLASS TOP	2


HARDWARE LIST			
NO.		HARDWARE DESC	QTY
1		ALLEN BOLT (1/4"-20 x 1-3/4")	4
2		SPRING WASHER(1/4")	4
3		FLAT WASHER (1/4"-20 x 5/8")	4
4		BRACKET (4"x1-3/16" x 1/8")	8
5		ALLEN BOLT (1/4" x 3/4")	24
6		WOOD DOEWELS (Ø8 x1-3/16")	4
7		ALLEN KEY(M4)	1

⚠ Only tighten all bolts when all bolts aligned with bolt inserts.

STEP : 1




STEP : 2




Assembly Instruction

TEA TABLE

STEP : 3



STEP : 4



COMPLETED

