

User Manual

Massage Cushion

Important Safety Instruction

When using the product, all instructions and basic precautions should always be followed, including the following:

DANGER

To reduce the risk of electric shock:

Always unplug this product from the electrical outlet immediately after using and before cleaning.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

01. The product should never be left unattended when plugged in. Unplug from outlet when it is not used and before putting on or taking off parts.
02. Do not operate under a blanket or a pillow. Excessive heat can occur and cause fire, electric shock, or injury to persons.
03. Do not carry this product by its supply cord or use the cord as a handle.
04. Never operate the product with the air openings blocked. Keep the air openings free of lint, hair, and the like.
05. Do not drop or insert any object into any opening.
06. Do not use outdoors.
07. Do not operate where aerosol (spray) products are being used or where oxygen is administered.
08. To disconnect, switch off all controls and remove the plug from outlet.

09. Close supervision is necessary when this appliance is used by, or near children, invalids, or disabled persons to ensure that they do not misuse the product.
10. Keep the cord away from heated surface, otherwise it may cause serious burns. Do not use over insensitive skin areas or in the presence of poor circulation.
11. The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
12. The appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.
13. The appliance is only to be used with the power supply unit provided with the appliance.
14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or persons lacking experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
15. Special attention should be given to components most susceptible to wear and it's advised to replace defective components immediately and/or keep the equipment out of use until repair.
16. Use this appliance only for its intended use as described in this manual.
17. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has dropped into water. Return the appliance to a service center for examination and repair.



- Do not wash!
- Do not dry clean!
- After using this product for 15 minutes, rest for 30 minutes, then use again.



The device is not to be used for commercial use or medical purposes. If you have health concerns, consult your doctor before using the product.



Only use indoors!



Do not use the device in damp rooms (e.g. when bathing or showering).

SAVE THESE INSTRUCTIONS

Introduction:

Thank you for purchasing the Shiatsu Back Massager with Kneading and Heating. Please read this user manual carefully and keep it in a safe place for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

Included:

- 1 × Massage Cushion
- 1 × Power Adapter
- 1 × Car Adapter
- 1 × User Manual

Easy-to-use Controller: Easily customize your massage to suit your preference.

Versatile and Portable: Turn your sofa or seat into a massage chair.

Home, Office or Car Use: The straps on the back help fix the massager securely on most chairs or car seats.

Please note: While driving, the massager can be used on the passenger seats, but never on the driver's seat.

Product Specifications:

Product: Massage Cushion

Dimensions (mm): 450 L x 400 W x 700 H

Weight: 2.9 kg

Output: 12V  2A

Enclosure material: PU, Nylon, Polyester, Latex, Resins

Output cable & Accessories: 1.8m cable, Power Adaptor & Car Adapter

Product Description:

Full Back Shiatsu Massager has two pairs of rotating masage nodes which simulate the pressure and kneading motions of shiatsu massage. The upgraded 3D massage nodes are designed to better target the acupoints on your back and fit the contours of your body. The massage nodes move along the entire back offering a powerful and intense massage, which imitates the massage by an actual masseuse. Soothing heat provides comfortable relief for muscles and joints.

Invigorating Shiatsu Back Massage: Enjoy comfortable kneading massage and customize the massage according to your need.

New & Improved 3D Massage Nodes: 3D massage nodes provide optimal pressure for the acupoints on your body for more effective and invigorating massage.

Soothing Heat: Optional heat relieves muscle stress.

Seat Vibration: Vibration with adjustable intensity helps refresh you.

Timer Selector: Choose massage time among 3 settings - 5, 10, or 15 minutes. Shuts off automatically after 15 minutes of continuous use.